

NATIONAL ADVISORY COMMITTEE FOR AERONAUTICS

WARTIME REPORT

ORIGINALLY ISSUED

August 1945 as
Advance Restricted Report L5F15

CHARTS FOR THE MINIMUM-WEIGHT DESIGN OF 24S-T ALUMINUM-ALLOY

FLAT COMPRESSION PANELS WITH LONGITUDINAL

Z-SECTION STIFFENERS

By Evan H. Schuette

Langley Memorial Aeronautical Laboratory
Langley Field, Va.



NACA

WASHINGTON

NACA WARTIME REPORTS are reprints of papers originally issued to provide rapid distribution of advance research results to an authorized group requiring them for the war effort. They were previously held under a security status but are now unclassified. Some of these reports were not technically edited. All have been reproduced without change in order to expedite general distribution.

NACA ARR No. L5F15

NATIONAL ADVISORY COMMITTEE FOR AERONAUTICS

ADVANCE RESTRICTED REPORT

CHARTS FOR THE MINIMUM-WEIGHT DESIGN OF 2₁4S-T ALUMINUM-ALLOY
FLAT COMPRESSION PANELS WITH LONGITUDINAL
Z-SECTION STIFFENERS

By Evan H. Schuette

SUMMARY

Design charts are developed for 2₁4S-T aluminum-alloy flat compression panels with longitudinal Z-section stiffeners. These charts make possible the design of the lightest panels of this type for a wide range of design requirements. Examples of the use of the charts are given and it is pointed out on the basis of these examples that, over a wide range of design conditions, the maintenance of buckle-free surfaces does not conflict with the achievement of high structural efficiency. The achievement of the maximum possible structural efficiency with 2₁4S-T aluminum-alloy panels, however, requires closer stiffener spacings than those now in common use.

INTRODUCTION

In a longitudinally stiffened compression panel, in which all the material is active in carrying load, the requirement of minimum weight is tantamount to that of carrying the load at the highest possible average stress. The average stress developed by such a panel under the loading conditions imposed is thus a direct measure of the structural efficiency of the panel. If longitudinally stiffened compression panels are to be designed for high structural efficiency without a large number of cut-and-try computations, it is desirable that design charts be prepared to indicate the average stress attainable under various loading conditions. The preparation of such charts requires that a suitable design parameter in which the important loading conditions are incorporated be found.

It has been found that a suitable parameter for longitudinally stiffened compression panels in the design of which the transverse stiffness can be neglected

is $\frac{P_1}{L/\sqrt{c}}$, where P_1 is the compressive load per inch

of panel width, L is the panel length, or distance between supporting ribs, and c is the coefficient of end fixity at the ribs. The quantity P_1 , which is essentially independent of the distribution of material in the compression panel, can be estimated for a wing panel from the bending moment on the wing and the thickness and chord of the wing. The length L may be fixed by the presence of such installations as fuel tanks or armament or may be arbitrarily assigned for the purpose of arriving at a trial design.

In reference 2 buckling stresses were plotted against the parameter $\frac{P_1}{L/\sqrt{c}}$, with slightly different notation, to form the basis of a theoretical study of the efficiencies of various types of stiffening elements. In the present paper the same parameter has been used as a basis for the preparation of design charts from extensive test data on 24S-T aluminum-alloy flat compression panels with longitudinal Z-section stiffeners; the data were obtained from reference 1 and from additional tests completed since publication of reference 1. These charts make possible the choice of the lightest panels of this type to conform to a wide range of design conditions. An appendix is presented in which the procedure followed in preparing the charts from test data is described and the method for obtaining $\frac{P_1}{L/\sqrt{c}}$ as a natural parameter against which the average stress may be plotted to obtain a direct measure of structural efficiency is developed.

SYMBOLS AND DEFINITIONS

The symbols used for the principal panel cross-sectional dimensions are indicated in figure 1. In addition, the following symbols are used:

A_1	cross-sectional area per inch of panel width, or equivalent thickness of panel, inches
L	length of panel, inches
P_1	compressive load per inch of panel width, kips per inch
E_c	modulus of elasticity in compression, ksi
c	coefficient of end fixity as used in Euler column formula
k	coefficient in formula for local-buckling stress
ρ	radius of gyration of panel cross section, inches
τ	nondimensional coefficient that takes into account reduction in effective modulus of elasticity when panel fails as a column beyond the elastic range
σ_{cr}	critical stress, or stress for local buckling, ksi
$\bar{\sigma}_c$	average stress at column failure, ksi
$\bar{\sigma}_{max}$	average stress at local failure, ksi
$\bar{\sigma}_f$	average stress at failure for any panel, ksi

The average stress at which any particular panel fails, $\bar{\sigma}_f$, may be a local-failure stress, a column-failure stress, or the stress for a type of failure intermediate to these two. Failure by twisting of the stiffeners is included as a form of local failure. Because the design charts are based on actual test data, it is not necessary to make any distinction between local and twisting failure. Such a distinction, moreover, would be at best an arbitrary one, as the two types of failure are interrelated in the case of stiffened panels.

It should be noted that the local-failure stress $\bar{\sigma}_{max}$, which represents the maximum value of average stress that can be achieved in a given cross section as the panel length is reduced, is an average stress at failure and is not to be confused with the stress for local buckling σ_{cr} , which does not necessarily imply failure.

The term "local buckling" as used herein includes both buckling of the skin and buckling of the stiffeners, because neither of these elements can buckle without exerting moments on, and thus causing deformation of, the other element.

DESIGN CHARTS

Design charts for 24S-T aluminum-alloy flat compression panels with longitudinal Z-section stiffeners are presented in figures 2 to 5. The procedure used in the preparation of these charts from test data is described in the appendix. Values of A_i/t_s , necessary for arriving at a final design, are given in tables 1 to 3 for a wide range of dimension ratios.

In order to show the maximum stresses attainable by the use of panels of the type to which the charts apply, envelopes are indicated by the dashed lines for each value of the ratio b_s/t_s in figures 2 to 5. These envelopes have been combined (fig. 6) to give the over-all envelopes for the four values of the ratio t_w/t_s . The values of b_s/t_s and b_w/t_w needed in order that a panel will develop the stress indicated by an envelope are also given in figure 6.

The design parameter $\frac{P_1}{L/\sqrt{c}}$, against which stress is plotted in figures 2 to 6, comprises the principal design conditions: the compressive load per inch of panel width; the length of panel, or distance between supporting ribs; and the coefficient of end fixity. The most efficient (lightest) panel for a given combination of these conditions is that panel which will develop the highest average stress for the particular value of $\frac{P_1}{L/\sqrt{c}}$.

Discussion of charts.— The charts include a wide range of panel proportions. All the charts have been drawn for a value of $\frac{b_F}{b_w} = 0.4$; it is shown in the appendix (figs. 17 to 20), however, that curves for $\frac{b_F}{b_w} = 0.3$ and 0.5 would be in close agreement.

with the curves for $\frac{b_F}{b_W} = 0.4$. The curves of figures 2 to 5 may therefore be applied with reasonable accuracy for any value of b_F/b_W between 0.3 and 0.5. The available test data seem to indicate, moreover, that the most efficient use of material will be realized if a proportion in this range is selected. (See appendix.)

The short horizontal lines that intersect the curves of figures 2 to 5 indicate, for each panel cross section having appreciable local buckling, the stress at which this buckling occurs. In this report this stress is taken as that at which the compressive strain on one side of the skin or the stiffener web begins to be reduced with increasing load. This definition of buckling is convenient for structural testing; from the standpoint of aerodynamic smoothness, appreciable buckling probably takes place at stresses somewhat lower than those indicated on the charts. It will be noted that for some of the lower values of b_S/t_S and b_W/t_W no buckling stress is shown. In these cases, there will undoubtedly be some buckling but presumably it will occur at a stress coincident with or only very slightly below the failure stress.

It is pointed out that for $\frac{t_W}{t_S} = 0.79$ and 1.00 (figs. 4 and 5), the curves for values of $\frac{t_S}{t_S} = 25$ and 30

have been obtained entirely by extrapolation. These curves should therefore be used with a certain degree of caution. A few check tests made since the preparation of the charts, however, indicate that the curves will in no case be more than 6 percent unconservative. In all the other curves, it is believed that any unconservatism that may be present is of much smaller magnitude.

Discussion of tests and test panels.- In order that the design charts may be properly used, it is necessary to know something of the test panels and the test results on which the design charts are based. The details of these tests are described in reference 1; some of the pertinent information regarding the tests follows:

The test panels consisted of six stiffeners and five bays. The panels were tested flat-ended and without edge support. A fixity coefficient of 3.75 was used in reducing the test data for application to an effective pin-ended length. The average compressive yield strength for the material of which the test panels were constructed was about 44 ksi; the minimum yield strength, about 41 ksi; and the maximum yield strength, about 46.5 ksi. The rivets were countersunk and were driven by the

NACA method of inserting a flat-head rivet from the stiffener side of the hole, upsetting the rivet shank into the countersunk cavity, and milling off the protruding portion of the upset shank. The rivets were Al7S-T (AN442AD) and were of the sizes and spacings indicated by the following table:

$\frac{t_w}{t_s}$	Rivet spacing t_s	Rivet diameter t_s
0.51	10.0	1.50
.63	12.3	1.84
.79	12.3	1.93
1.00	11.7	1.95

Because the compressive strength of stiffened panels may be affected by the size and spacing of the rivets used to attach stiffeners to skin (reference 3), the rivet attachment must be equivalent to that indicated by the foregoing table in order to be sure of realizing the strengths indicated by the design charts.

USE OF DESIGN CHARTS AND EXAMPLES

If sheet material could be obtained in any desired thickness and if no special limitations were put on the design, it would be sufficient merely to find those proportions that would give the highest stress for the

given value of $\frac{F_i}{L/\sqrt{c}}$. Because certain limitations are usually imposed, however, the structure that represents the best compromise of all the requirements must be chosen.

The usual gages in which aluminum-alloy sheet is manufactured are such that if the four ratios of t_w/t_s in figures 2 to 6 are applied consecutively to a particular skin gage, the four stiffener gages that result will generally be consecutive standard gages. Interpolation between the curves of two consecutive charts (figs. 2 and 3, 3 and 4, etc.) is therefore unnecessary for most practical purposes.

The particular procedure to be used in obtaining a design from the charts will depend on the nature of the results desired. Three possible methods are discussed, and examples are given of designs obtained for a given load intensity and three different lengths by each of the methods.

The distinguishing features of each method are:

Ideal design

The method for obtaining the ideal design gives the lightest panel that could be obtained if the designer were not restricted to the use of standard sheet gages. The design is obtained by use of the over-all envelopes of figure 6 only.

Short method

The short design method provides, without lengthy computation, a near approach to the lightest panel that can be obtained by use of standard sheet gages. The design is obtained by use of the envelopes for given values of b_s/t_g that appear as dashed lines in figures 2 to 5.

Maximum efficiency

The method of designing for maximum structural efficiency gives the lightest panel that can be obtained by use of standard sheet gages. The design is obtained through a complete study of the individual solid curves in figures 2 to 5. The method is somewhat lengthy; examples have been worked out by its use, however, to serve as a check on the short method, so that that method can be used with confidence.

Each of the three methods is given as a series of steps for reaching the final designs. In the method for obtaining the ideal design, the detailed computations for the four values of t_w/t_g included in figure 6 are given for $L = 10, 20$, and 30 inches with $P_1 = 3.0$ kips per inch and $c = 1$. In the other two methods, the detailed computations are given only for $L = 20$ inches and $\frac{t_w}{t_g} = 0.79$, again with $P_1 = 3.0$ kips per inch and $c = 1$; final results are given, however, for the complete set of examples considered in the discussion of the first method. It is assumed in all cases that a skin thickness of 0.064 inch is necessary in order to comply with other design requirements. A value of b_p/b_w of 0.4 is used throughout. In arriving at the final designs, no values of the dimension ratios outside of the ranges covered by the charts are given consideration.

Method for obtaining the ideal design. - This method consists of picking from figure 6 the optimum proportions and the stress and computing from these the actual panel dimensions.

The values and computed quantities for the conditions previously mentioned are given in table 4 and are referenced to the steps in the following procedure:

(1) Compute $\frac{P_1}{L/\sqrt{c}}$.

(2) From the curves of figure 6 pick off for each value of t_w/t_s the values of b_s/t_s , b_w/t_w , and $\bar{\sigma}_f$ corresponding to the value of $\frac{P_1}{L/\sqrt{c}}$.

(3) Pick from table 2 the values of A_1/t_s for the ratios determined in step 2. (If $\frac{b_w}{b_s} = 0.3$ or 0.5 is used, table 1 or table 3, respectively, should be used instead of table 2.)

(4) Compute

$$t_s = \frac{P_1}{\bar{\sigma}_f \frac{A_1}{t_s}}$$

This formula is based on the equality

$$P_1 = \bar{\sigma}_f A_1$$

(5) Compute

$$t_w = \frac{t_w}{t_s} t_s$$

$$b_s = \frac{b_s}{t_s} t_s$$

$$b_w = \frac{b_w}{t_w} t_w$$

This procedure results in four designs for each length, corresponding to the four values of t_w/t_s , for

the given conditions. (See table 4.) The values marked with footnote a in table 4 represent those chosen as approaching most closely the desired condition of $t_s = 0.064$ inch; these values therefore give an indication of the proportions needed in a practical design to meet the design requirements most efficiently.

The resulting designs are shown as the ideal designs at the tops of figures 7 to 9, along with bar graphs of the average stress at failure and the buckling stress. The buckling stress for each design was obtained by interpolation from the short horizontal lines for buckling in figures 2 to 5. In some cases in which failure is by column action, the buckling stress shown by figures 2 to 5 will be greater than the failure stress for the designs obtained. Whenever this difference occurred in the present examples, the buckling stress is shown equal to the failure stress.

Short method for obtaining a practical design.- The short method consists of picking the optimum value of b_w/t_w and the corresponding stress for each value of b_s/t_s from the individual envelopes of figures 2 to 5 and computing from these values the actual panel dimensions. Panel designs that employ standard sheet gages are then selected from the various designs obtained.

The values and computed quantities for $L = 20$ inches and $\frac{t_w}{t_s} = 0.79$ are given in table 5 and are referenced to the steps in the following procedure:

$$(1) \text{ Compute } \frac{P_i}{L/\sqrt{c}}.$$

(2) From the curves for a particular value of t_w/t_s , (in this example, fig. 4 for $\frac{t_w}{t_s} = 0.79$ is used) pick off for each value of b_s/t_s the values of b_w/t_w (by interpolation along the dashed envelope) and $\bar{\sigma}_f$ (from the envelope) corresponding to the value of $\frac{P_i}{L/\sqrt{c}}$.

(3) Pick from table 2 the values of A_1/t_s for the ratios determined in step 2.

(4) Compute

$$t_S = \frac{P_i}{\bar{\sigma}_f \frac{A_i}{t_S}}$$

(5) Plot b_w/t_w , t_S , and $\bar{\sigma}_f$ against b_S/t_S for the particular value of t_w/t_S . (The plot for the example being considered is shown in fig. 10.) Tabulate the values of b_S/t_S , b_w/t_w , and $\bar{\sigma}_f$ corresponding to the point where t_S equals the specified value.

(6) Check computations by picking from table 2 the value of A_i/t_S corresponding to the ratios tabulated in step 5. If all computations and plots are correct,

$$P_i = \bar{\sigma}_f \frac{A_i}{t_S} t_S$$

(7) Compute

$$t_w = \frac{t_w}{t_S} t_S$$

$$b_S = \frac{b_S}{t_S} t_S$$

$$b_w = \frac{b_w}{t_w} t_w$$

(8) Repeat steps 2 to 7 for other values of t_w/t_S .

Like that for the ideal design, this procedure results, for each length considered, in one design for each value of t_w/t_S . It may not always be possible to find satisfactory designs under the conditions imposed for all values of t_w/t_S . (Note that no designs are given in figs. 8 and 9 for $\frac{t_w}{t_S} = 0.51$.) All the designs resulting from the use of the short method utilize standard sheet gages and meet the requirement that $t_S = 0.064$ inch. The choice of design now depends on arriving at a suitable compromise between high stress and wide stiffener spacing.

If the prevention of buckling under load is considered important, then the buckling stress must also be taken into account in making a choice.

The designs obtained by carrying out the foregoing procedure for the several values of L and t_w/t_s are shown as the short-method designs in figures 7 to 9 along with bar graphs of the average stress at failure and the buckling stress.

Method of designing for maximum structural efficiency.— The maximum-efficiency method consists of computing the thickness required as b_s/t_s is varied for each value of b_w/t_w and selecting the designs for which the skin gage is equal to that desired. The procedure results in a series of possible designs for each value of t_w/t_s , from which those designs that provide the highest average stress at failure can be selected.

The values and computed quantities for $L = 20$ inches and $\frac{t_w}{t_s} = 0.79$ are given in table 6 and are referenced to the steps in the following procedure:

$$(1) \text{ Compute } \frac{P_1}{L/\sqrt{c}}.$$

(2) From the curves for a particular value of $\frac{t_w}{t_s}$ (in this example, fig. 4 for $\frac{t_w}{t_s} = 0.79$ is used) pick off for each value of b_w/t_w and b_s/t_s the value of $\bar{\sigma}_f$ corresponding to the value of $\frac{P_1}{L/\sqrt{c}}$.

(3) Pick from table 2 the values of A_1/t_s corresponding to the ratios used in step 2.

(4) Compute

$$t_s = \frac{P_1}{\bar{\sigma}_f \frac{A_1}{t_s}}$$

(5) Plot t_s and $\bar{\sigma}_f$ against b_s/t_s for each value of b_w/t_w and t_w/t_s . Plot the particular value

of b_w/t_w at the value of b_S/t_S for which t_S equals the specified value and mark the value of stress at that value of b_S/t_S . The plots of this step for the example under consideration are given in figure 11 as the short lines for the several values of b_w/t_w indicated. In order to avoid unnecessary confusion, only short portions of the curves, except the curve for $\frac{b_w}{t_w} = 20$, are shown.

(6) After step 5 has been completed for all the values of b_w/t_w , draw curves of stress and of b_w/t_w against b_S/t_S through the points determined in step 5 (heavy curves in fig. 11).

(7) Each of the curves drawn in step 6 represents a series of designs, all of which have the required value of t_S (in this case, 0.064 in.). The maximum point on the curve of $\bar{\sigma}_f$ indicates the design for maximum structural efficiency for the particular value of t_w/t_S . Note this maximum value of $\bar{\sigma}_f$, the value of b_S/t_S at which it is reached, and the value of b_w/t_w , which can be picked from the curve of b_w/t_w against b_S/t_S .

(8) Check computations by picking from table 2 the value of A_1/t_S corresponding to the ratios selected for maximum structural efficiency in step 7. If all computations and plots are correct,

$$P_1 = \bar{\sigma}_f \frac{A_1}{t_S} t_S$$

(9) Compute

$$t_w = \frac{t_w}{t_S} t_S$$

$$b_S = \frac{b_S}{t_S} t_S$$

$$b_w = \frac{b_w}{t_w} t_w$$

(10) Repeat steps 2 to 9 for other values of t_w/t_S .

This procedure results, for each length considered, in one design for each value of t_w/t_s . The choice of a design depends on arriving at a suitable compromise between high stress and wide stiffener spacing, with possible consideration for the buckling stress.

The designs obtained by carrying out the foregoing procedure for the several values of L and t_w/t_s are shown as the maximum-efficiency designs in figures 7 to 9 along with bar graphs of the average stress at failure and the buckling stress.

DISCUSSION

Figures 7 to 9 provide a visual comparison of the designs that result from use of the three methods presented. The short method of design gives in every case an average stress at failure very close to that obtained by designing on the basis of maximum structural efficiency; the buckling stress, however, is in some cases somewhat lower than that for the maximum-efficiency panel.

Whether the design obtained by the short method or the design for maximum efficiency is selected, the best design for $P_1 = 3.0$ kips per inch, on the basis of stress, is obtained at $L = 10$ inches with $\frac{t_w}{t_s} = 0.51$, at $L = 20$ inches with $\frac{t_w}{t_s} = 0.63$, and at $L = 30$ inches with $\frac{t_w}{t_s} = 0.79$. In figure 6, however, the highest envelope, which gives the lightest design, is that for $\frac{t_w}{t_s} = 1.00$. This apparent contradiction results from the fact that in working out the examples a skin thickness of 0.064 inch was specified. In order to reach the curve for $\frac{t_w}{t_s} = 1.00$ (fig. 6), a study of table 4 shows that the skin thickness would have to be 0.034 inch at $L = 10$ inches, 0.041 inch at 20 inches, and 0.046 inch at 30 inches. Moreover, the stiffener spacings for designs having such small skin thicknesses are very small. (See table 4.) Because of limitations

on skin gages and stiffener spacings, therefore, it is frequently not possible to reach the envelope values of stress and hence the lowest possible weight.

Figures 7 to 9 show that the best panel (that with highest σ_f) obtained at each length by the maximum-efficiency method does not buckle until failure or very close to failure. The best panel designed by the short method, although it may not have quite so high an average stress at failure as the maximum-efficiency panel, also does not buckle until very close to failure. This condition has been found to hold true over a wide range of design requirements. It is therefore evident that over a wide range of conditions the maintenance of buckle-free surfaces does not conflict with the achievement of high structural efficiency. The simultaneous achievement of both these ends by use of 24S-T aluminum-alloy panels, however, apparently requires closer stiffener spacings than those now in common use. For example, the maximum-efficiency designs for $P_1 = 3.0$ kips per inch and $t_s = 0.064$ inch have the following spacings for the three lengths:

L (in.)	$\frac{b_s}{t_s}$	b_s (in.)
10	28.0	1.79
20	42.1	2.69
30	40.0	2.56

CONCLUDING REMARKS

Charts are presented for the minimum-weight design of 24S-T aluminum-alloy flat compression panels with longitudinal Z-section stiffeners. From examples based on the use of these charts, it is concluded that, over a wide range of design conditions, the maintenance of buckle-free surfaces on longitudinally stiffened compression panels does not conflict with the achievement of high structural efficiency. The achievement of the maximum possible structural efficiency with

2¹/₂S-T aluminum-alloy panels, however, requires closer stiffener spacings than those now in common use.

Langley Memorial Aeronautical Laboratory
National Advisory Committee for Aeronautics
Langley Field, Va..

APPENDIX

METHOD OF PREPARATION OF DESIGN CHARTS

Development of design parameter $\frac{P_i}{L/\sqrt{c}}$. - As stated in the Introduction, the average stress developed by a longitudinally stiffened compression panel is a direct measure of the structural efficiency of the panel. It is further brought out that a suitable design parameter against which this average stress may be plotted

is $\frac{P_i}{L/\sqrt{c}}$, where P_i is the compressive load per inch of panel width, L is the panel length or distance between supporting ribs, and c is the coefficient of end fixity at the ribs.

The following derivation shows how the parameter $\frac{P_i}{L/\sqrt{c}}$ evolves from the usual column formula:

The column formula may be written

$$\bar{\sigma}_c = \frac{\pi^2 \tau E_c}{\left(\frac{L}{\rho \sqrt{c}}\right)^2} \quad (A1)$$

Multiplication and division of the right-hand side of equation (A1) by P_i^2 gives

$$\bar{\sigma}_c = \pi^2 \tau E_c \left(\frac{\rho}{P_i}\right)^2 \left(\frac{P_i}{L/\sqrt{c}}\right)^2 \quad (A2)$$

If the stiffened panel is to have a strength just equal to that required by the design conditions, $P_i = A_i \bar{\sigma}_c$ and equation (A2) may therefore be written

$$\bar{\sigma}_c = \pi^2 \tau E_c \left(\frac{\rho}{A_i}\right)^2 \left(\frac{P_i}{L/\sqrt{c}}\right)^2 \left(\frac{1}{\bar{\sigma}_c}\right)^2$$

or

$$\frac{\bar{\sigma}_c^3}{\tau} = \pi^2 E_c \left(\frac{\rho}{A_1}\right)^2 \left(\frac{P_1}{L/\sqrt{c}}\right)^2$$

which may be written

$$\frac{\bar{\sigma}_c}{\sqrt{\tau}} = \sqrt[3]{\pi^2 E_c} \left(\frac{\rho}{A_1}\right)^{2/3} \left(\frac{P_1}{L/\sqrt{c}}\right)^{2/3} \quad (A3)$$

The quantity $\sqrt[3]{\pi^2 E_c}$ in equation (A3) is fixed for a given material, as is the relationship between $\bar{\sigma}_c$ and τ , except for negligible shape effects. The quantity $\frac{P_1}{L/\sqrt{c}}$ is the design parameter; ρ/A_1 is dimensionless and is determined by the relative rather than the absolute dimensions of a panel. A plot of $\bar{\sigma}_c$ against $\frac{P_1}{L/\sqrt{c}}$ is therefore dependent on the ratios of the various panel dimensions and not on the absolute values of the dimensions.

Determination of average stress at local failure $\bar{\sigma}_{max}$.

From equation (A3), the best panel of a given material for any value of $\frac{P_1}{L/\sqrt{c}}$ on the basis of column strength

apparently is that panel which has the highest value of ρ/A_1 . Changes in proportions that result in an increase in ρ/A_1 will, however, generally cause a decrease in the local-failure strength of the panel.

(Local failure as used herein includes the phenomenon of twisting, which is in reality only a form of local failure that occurs when the lateral bending stiffness of the outstanding stiffener flange is relatively small.) The optimum panel for a particular application is given by the compromise of column and local-failure strengths that gives the highest stress at the given value

of $\frac{P_1}{L/\sqrt{c}}$.

The value of the average stress at local failure $\bar{\sigma}_{\max}$ is difficult to determine theoretically. Certain test data are available, however, from reference 1 and from additional tests completed since the publication of reference 1. Those data that were obtained from the shortest panels of each cross section are summarized in figure 12, in which $\bar{\sigma}_{\max}$ is plotted against t_w/b_w for various values of t_w/t_s and b_s/t_s . The ratio b_w/t_w has been inverted in this plot in order that the additional point $\bar{\sigma}_{\max} = 0$ when $\frac{t_w}{b_w} = 0$ ($\frac{b_w}{t_w} = \infty$) might be used to aid in fairing curves through the test points. The plots of figure 12 make possible an interpolation of $\bar{\sigma}_{\max}$ between test points for intermediate values of the ratio b_w/t_w . By plotting values of $\bar{\sigma}_{\max}$ picked from the curves of figure 12 against t_s/b_s , values of $\bar{\sigma}_{\max}$ were also determined for intermediate values of b_s/t_s .

All the data shown in figure 12 are for a value of $\frac{b_F}{b_w} = 0.4$. Test data for $\frac{b_F}{b_w} = 0.3$ and 0.5, however, were also employed as a guide in fairing the curves, and the curves will be shown to be reasonably accurate for any value of b_F/b_w between 0.3 and 0.5.

Determination of stress for local buckling σ_{cr} .- If the panel did not buckle locally before failure, the theoretical results thus far presented, used in conjunction with values of $\bar{\sigma}_{\max}$, would be sufficient to

construct a design curve of $\bar{\sigma}_f$ against $\frac{P_1}{L/\sqrt{c}}$ for any

panel. A typical curve for panels that do not buckle before failure is shown in figure 13. Unless the width-thickness ratios of the various plate elements of the panel are small or the panel is relatively long, however, there will generally be some local buckling before failure. When this buckling takes place, the cross-sectional moment of inertia of the panel is reduced by the presence of ineffective areas; the original curve of column strength therefore no longer applies and the point at which buckling takes place must be connected with the line for local failure by means of a reduced curve. A typical curve, adjusted for the effects of local buckling, is shown in figure 14.

The foregoing discussion shows that it is necessary to know the stress at which buckling takes place. Data on buckling stresses from reference 1 plus additional data now available are therefore plotted in figure 15

for $\frac{b_F}{b_W} = 0.4$. Because the measured value of b/t for

the element (skin or stiffener web) that first showed buckling in a test panel was never in exact agreement with the specified nominal value, the observed buckling stresses from reference 1 were corrected for use in figure 15 according to the following formula:

$$(\sigma_{cr})_{\text{corrected}} = (\sigma_{cr})_{\text{observed}} \frac{\left(\frac{b}{t}\right)^2_{\text{measured}}}{\left(\frac{b}{t}\right)^2_{\text{nominal}}}$$

where the value of b/t is that for the web of the stiffener or for the skin between stiffeners, depending on which of these elements first gave evidence of buckling. This correction formula is based on the fact that, other factors being equal, the critical stress is inversely proportional to the square of the width-thickness ratio. No account is taken herein of the fact that this relationship is not entirely true for stresses beyond the elastic range; it is assumed that neglecting this fact will have no significant effect because the total correction is relatively small.

The method used in fairing curves through the test points in figure 15 is as follows:

For the horizontal portions of the curves on the right-hand side of figure 15, the skin is primarily responsible for the buckling; the ordinates for the curves in this region are determined by drawing average lines through the test points. As the value of t_W/b_W is reduced, however, the responsibility for the buckling shifts to the stiffeners and there is a reduction in σ_{cr} . In the absence of adequate test data for low values of t_W/b_W , certain theoretical considerations are used for determining the values of σ_{cr} in this region.

It is possible to describe certain limiting conditions that determine curves between which the correct curves must lie. As the value of t_w/b_w approaches zero, with all other dimension ratios held constant, the skin tends to become infinitely stiff by comparison with the stiffener and the stiffener approaches a condition of complete fixity at the edge where it is attached to the skin. This condition of complete fixity represents the upper limit of buckling stress. The value of k , the coefficient in the formula for local-buckling stress (reference 4), when applied to the stiffener web may be taken for this condition as the geometric mean of the value of k for the web of a Z-section column

with $\frac{b_F}{b_w} = 0.4$ (about 3.77, see reference 4) and the

value of k for a flat plate fixed at both edges (about 6.98, see reference 5). This value of k is $\sqrt{3.77 \times 6.98}$, or 5.13. The upper dashed curve in figure 15 gives σ_{cr} for $k = 5.13$. The use of the geometric mean of values of k to obtain the critical stress for a plate with different restraints along the two unloaded edges is discussed and justified for practical use in reference 5.

When $\frac{b_w}{t_w} = \frac{b_S}{t_S}$, it is a reasonable and probably

conservative assumption to consider the stiffener hinged at the edge where it is attached to the skin. This hinged condition represents the lower limit of buckling stress. The value of k for the web of the stiffener may be taken for this condition as the geometric mean of 3.77 for the simple Z-section and the value for a flat plate hinged at both edges (4.00, see reference 5) or $k = \sqrt{3.77 \times 4.00} = 3.88$. The lower dashed curve in figure 15 gives σ_{cr} for $k = 3.88$. In the preparation of the two dashed curves, the effect of reduction in the modulus of elasticity for stresses beyond the elastic range was determined from figure 8 of reference 6.

The solid curve on the left-hand side of figure 15 is drawn in to give a gradual transition from the lower dashed curve in the region where $\frac{b_w}{t_w} = \frac{b_S}{t_S}$ toward the upper dashed curve as t_w/b_w approaches zero. In the

region where $\frac{b_w}{t_w} = \frac{b_s}{t_s}$ the curves are faired into the horizontal lines drawn through the test points. A single curve was considered sufficient for all values of t_w/t_s for the left-hand portion of figure 15, because the few test points that were available in this region indicated that the individual curves would be so close together as to be almost indistinguishable.

The curves of figure 15, like those of figure 12, were cross-plotted to give buckling stresses for the intermediate values of b_s/t_s that appear in figures 2 to 5.

Preparation of final curves.— The procedure used in the preparation of the final curves of figures 2 to 5 is illustrated in figure 16. An outline of this procedure is as follows:

(1) Draw curve for column strength corresponding to the value of ρ/A_1 for the panel cross section. For the curves of this report, the column curve for 24S-T aluminum alloy was obtained from equations (5) and (6) and table I, all of reference 7.

(2) Plot the values of stress for local buckling and for local failure of panel obtained from the cross plots of the curves in figures 12 and 15.

(3) Plot available test data and fair curves between buckling stress and local-failure stress. This fairing was done first for those curves for which test data were available; the remaining curves were then faired in a manner consistent with the curves already established.

In a few cases (low b_s/t_s with high b_w/t_w) the test data indicated that the curves did not follow the smooth transition between column and local failure indicated by figure 16. Instead the curves tended to bend over sharply, in some cases even below the buckling stress given by figure 15, and to follow very nearly a straight line up to the average stress for local failure. No explanation is offered for this phenomenon; the available test data were used as the sole guide for fairing the curves in these cases.

Correlation between design curves and test data.-
 The test data of reference 1 as well as the additional data made available since the publication of reference 1 are plotted against the parameter $\frac{P_i}{L/\sqrt{c}}$ in figures 17 to 20. Appropriate curves taken from figures 2 to 5 are also drawn in these figures and good agreement between the final design curves and the test data for $\frac{b_F}{b_W} = 0.4$. exists throughout the range of the data. In order to make it possible, if desired, to check the correlation on a larger-scale plot, the test data for $\frac{b_F}{b_W} = 0.3, 0.4,$ and 0.5 are given in table 7 in a form suitable for plotting directly on the design charts (figs. 2 to 5). Table 7 and figures 17 to 20 also make it possible to determine in which regions the design charts are substantiated by test data and in which regions they were obtained by interpolation or extrapolation.

Figures 17 to 20 indicate that there would be little difference in the curves for $\frac{b_F}{b_W} = 0.3, 0.4,$ and 0.5 but that the curves for $\frac{b_F}{b_W} = 0.2$ and probably 0.7 would be lower than those for $\frac{b_F}{b_W} = 0.4.$ The most efficient use of material will therefore be realized if a value of b_F/b_W between 0.3 and 0.5 is used. It is for this range that the design charts are intended to be used, although they are based on the specific data for $\frac{b_F}{b_W} = 0.4.$

REFERENCES

1. Rossman, Carl A., Bartone, Leonard M., and Dobrowski, Charles V.: Compressive Strength of Flat Panels with Z-Section Stiffeners. NACA ARR No. 4B03, 1944.
2. Zahorski, Adam: Effects of Material Distribution on Strength of Panels. Jour. Aero. Sci., vol. 11, no. 3, July 1944, pp. 247-253.
3. Dow, Norris F., and Hickman, William A.: Preliminary Investigation of the Relation of the Compressive Strength of Sheet-Stiffener Panels to the Diameter of Rivet Used for Attaching Stiffeners to Sheet. NACA RB No. 14113, 1944.
4. Kroll, W. D., Fisher, Gordon P., and Heimerl, George J.: Charts for Calculation of the Critical Stress for Local Instability of Columns with I-, Z-, Channel, and Rectangular-Tube Section. NACA ARR No. 3K04, 1943.
5. Lundquist, Eugene E., and Stowell, Elbridge Z.: Critical Compressive Stress for Flat Rectangular Plates Supported along All Edges and Elastically Restrained against Rotation along the Unloaded Edges. NACA Rep. No. 733, 1942.
6. Heimerl, George J., and Rcy, J. Albert: Preliminary Report on Tests of 24S-T Aluminum-Alloy Columns of Z-, Channel, and H-Section That Develop Local Instability. NACA RB No. 3J27, 1943.
7. Templin, R. L., Sturm, R. G., Hartmann, E. C., and Holt, M.: Column Strength of Various Aluminum Alloys. Tech. Paper No. 1, Aluminum Res. Lab. Aluminum Co. of Am., 1938.

TABLE 1

VALUES OF A_1/t_s FOR FLAT PANELS WITH Z-SECTION STIFFENERS. $\frac{b_F}{b_W} = 0.3$.

$$\left[\frac{A_1}{t_s} = 1 + \frac{\frac{b_W}{t_W} \left(1 + \frac{b_F}{b_W} \right) + \frac{b_A}{t_W} - \left(2 - \frac{\pi}{2} \right) \left(\frac{r_A}{t_W} + \frac{r_F}{t_W} + 1 \right)}{b_S/t_S} \left(\frac{t_W}{t_S} \right)^2 \right]$$

$$\frac{t_W}{t_S} = 0.51$$

b_W/t_W	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
b_S/t_S																					
25	1.353	1.367	1.380	1.394	1.407	1.421	1.435	1.448	1.462	1.475	1.489	1.516	1.543	1.570	1.597	1.624	1.651	1.678	1.705	1.732	1.759
26	1.340	1.353	1.366	1.379	1.392	1.405	1.418	1.431	1.444	1.457	1.470	1.496	1.522	1.548	1.574	1.600	1.626	1.652	1.678	1.704	1.730
27	1.327	1.340	1.352	1.365	1.377	1.390	1.402	1.415	1.427	1.440	1.452	1.477	1.502	1.528	1.553	1.578	1.603	1.628	1.653	1.678	1.703
28	1.316	1.328	1.340	1.352	1.364	1.376	1.388	1.400	1.412	1.424	1.436	1.460	1.485	1.509	1.533	1.557	1.581	1.605	1.629	1.654	1.678
29	1.305	1.316	1.328	1.340	1.351	1.363	1.375	1.386	1.398	1.410	1.421	1.445	1.468	1.491	1.514	1.538	1.561	1.584	1.608	1.631	1.654
30	1.294	1.306	1.317	1.328	1.340	1.351	1.362	1.373	1.385	1.396	1.407	1.430	1.452	1.475	1.497	1.520	1.555	1.587	1.610	1.633	1.655
31	1.285	1.296	1.307	1.318	1.329	1.340	1.350	1.361	1.372	1.383	1.394	1.416	1.438	1.459	1.481	1.503	1.525	1.547	1.569	1.590	1.612
32	1.276	1.287	1.297	1.308	1.318	1.329	1.339	1.350	1.361	1.371	1.382	1.403	1.424	1.445	1.466	1.487	1.509	1.530	1.551	1.572	1.593
33	1.268	1.278	1.288	1.298	1.309	1.319	1.329	1.339	1.350	1.360	1.370	1.391	1.411	1.432	1.452	1.473	1.493	1.514	1.534	1.555	1.575
34	1.260	1.270	1.280	1.290	1.300	1.310	1.320	1.329	1.339	1.349	1.359	1.379	1.399	1.419	1.439	1.459	1.479	1.498	1.518	1.538	1.558
35	1.252	1.262	1.272	1.281	1.291	1.301	1.310	1.320	1.330	1.339	1.349	1.368	1.388	1.407	1.426	1.446	1.465	1.484	1.504	1.523	1.542
36	1.245	1.255	1.264	1.274	1.283	1.292	1.302	1.311	1.321	1.330	1.339	1.358	1.377	1.396	1.414	1.433	1.452	1.471	1.490	1.508	1.527
37	1.239	1.248	1.257	1.266	1.275	1.284	1.294	1.303	1.312	1.321	1.330	1.348	1.367	1.385	1.403	1.422	1.440	1.458	1.476	1.495	1.513
38	1.232	1.241	1.250	1.259	1.268	1.277	1.286	1.295	1.304	1.313	1.321	1.339	1.357	1.375	1.393	1.410	1.428	1.446	1.464	1.482	1.499
39	1.227	1.235	1.244	1.253	1.261	1.270	1.279	1.287	1.296	1.305	1.313	1.331	1.348	1.365	1.383	1.400	1.417	1.435	1.452	1.469	1.487
40	1.221	1.229	1.238	1.246	1.255	1.263	1.272	1.280	1.288	1.297	1.305	1.322	1.339	1.356	1.373	1.390	1.407	1.424	1.441	1.458	1.474
42	1.210	1.218	1.226	1.234	1.243	1.251	1.259	1.267	1.275	1.283	1.291	1.307	1.323	1.339	1.355	1.371	1.387	1.404	1.420	1.436	1.452
44	1.201	1.208	1.216	1.224	1.232	1.239	1.247	1.255	1.262	1.270	1.278	1.293	1.308	1.324	1.339	1.354	1.370	1.385	1.401	1.416	1.431
46	1.192	1.199	1.207	1.214	1.221	1.229	1.236	1.244	1.251	1.258	1.266	1.280	1.295	1.310	1.324	1.339	1.354	1.368	1.383	1.398	1.413
48	1.184	1.191	1.198	1.205	1.212	1.219	1.226	1.233	1.240	1.247	1.254	1.269	1.283	1.297	1.311	1.325	1.339	1.353	1.367	1.381	1.395
50	1.177	1.183	1.190	1.197	1.204	1.211	1.217	1.224	1.231	1.238	1.244	1.258	1.271	1.285	1.298	1.312	1.325	1.339	1.353	1.366	1.380
52	1.170	1.176	1.183	1.189	1.196	1.202	1.209	1.215	1.222	1.228	1.235	1.248	1.261	1.274	1.287	1.300	1.313	1.326	1.339	1.352	1.365
54	1.164	1.170	1.176	1.182	1.189	1.195	1.201	1.207	1.214	1.220	1.226	1.239	1.251	1.264	1.276	1.289	1.301	1.314	1.326	1.339	1.351
56	1.158	1.164	1.170	1.176	1.182	1.188	1.194	1.200	1.206	1.212	1.218	1.230	1.242	1.254	1.266	1.279	1.291	1.303	1.315	1.327	1.339
58	1.152	1.158	1.164	1.170	1.176	1.181	1.187	1.193	1.199	1.205	1.211	1.222	1.234	1.246	1.257	1.269	1.281	1.292	1.304	1.316	1.327
60	1.147	1.153	1.159	1.164	1.170	1.175	1.181	1.187	1.192	1.198	1.204	1.215	1.226	1.237	1.249	1.260	1.271	1.282	1.294	1.305	1.316
65	1.136	1.141	1.146	1.152	1.157	1.162	1.167	1.172	1.178	1.183	1.188	1.198	1.209	1.219	1.230	1.240	1.250	1.261	1.271	1.282	1.292
70	1.126	1.131	1.136	1.141	1.146	1.150	1.155	1.160	1.165	1.170	1.175	1.184	1.194	1.203	1.213	1.223	1.232	1.242	1.252	1.261	1.271
75	1.118	1.122	1.127	1.131	1.136	1.140	1.145	1.149	1.154	1.158	1.163	1.172	1.181	1.190	1.199	1.208	1.217	1.226	1.235	1.244	1.253

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 1

 $\frac{b_F}{b_W} = 0.3 - \text{Continued}$
 $t_W = 0.63$
 t_S

b_S/t_S	b_W/t_W	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
25	1.531	1.552	1.573	1.593	1.614	1.635	1.655	1.676	1.696	1.717	1.738	1.779	1.820	1.862	1.903	1.944	1.985	2.027	2.068	2.109	2.151	
26	1.511	1.531	1.551	1.570	1.590	1.610	1.630	1.650	1.670	1.690	1.709	1.749	1.789	1.828	1.868	1.908	1.948	1.987	2.027	2.067	2.106	
27	1.492	1.511	1.530	1.549	1.568	1.588	1.607	1.626	1.645	1.664	1.683	1.721	1.760	1.798	1.836	1.874	1.912	1.951	1.989	2.027	2.065	
28	1.474	1.493	1.511	1.530	1.548	1.567	1.585	1.603	1.622	1.640	1.659	1.696	1.732	1.769	1.806	1.843	1.880	1.917	1.954	1.990	2.027	
29	1.458	1.476	1.494	1.511	1.529	1.547	1.565	1.583	1.600	1.618	1.636	1.672	1.707	1.743	1.778	1.814	1.849	1.885	1.921	1.956	1.992	
30	1.443	1.460	1.477	1.494	1.512	1.529	1.546	1.563	1.580	1.598	1.615	1.649	1.684	1.718	1.752	1.787	1.821	1.856	1.890	1.924	1.959	
31	1.428	1.445	1.462	1.478	1.495	1.512	1.528	1.545	1.562	1.578	1.595	1.628	1.662	1.695	1.728	1.761	1.795	1.828	1.861	1.895	1.928	
32	1.415	1.431	1.447	1.463	1.480	1.496	1.512	1.528	1.544	1.560	1.576	1.609	1.641	1.673	1.705	1.738	1.770	1.802	1.834	1.867	1.899	
33	1.403	1.418	1.434	1.449	1.465	1.481	1.496	1.512	1.528	1.543	1.559	1.590	1.621	1.653	1.684	1.715	1.747	1.778	1.809	1.840	1.872	
34	1.391	1.406	1.421	1.436	1.451	1.467	1.482	1.497	1.512	1.527	1.542	1.573	1.603	1.634	1.664	1.694	1.725	1.755	1.785	1.816	1.846	
35	1.380	1.394	1.409	1.424	1.438	1.453	1.468	1.483	1.497	1.512	1.527	1.556	1.586	1.615	1.645	1.674	1.704	1.733	1.763	1.792	1.822	
36	1.369	1.383	1.398	1.412	1.426	1.441	1.455	1.469	1.484	1.498	1.512	1.541	1.570	1.598	1.627	1.656	1.684	1.713	1.742	1.770	1.799	
37	1.359	1.373	1.387	1.401	1.415	1.429	1.443	1.457	1.471	1.485	1.498	1.526	1.554	1.582	1.610	1.638	1.666	1.694	1.722	1.749	1.777	
38	1.350	1.363	1.377	1.390	1.404	1.417	1.431	1.445	1.458	1.472	1.485	1.513	1.540	1.567	1.594	1.621	1.648	1.675	1.703	1.730	1.757	
39	1.341	1.354	1.367	1.380	1.394	1.407	1.420	1.433	1.446	1.460	1.473	1.499	1.526	1.552	1.579	1.605	1.632	1.658	1.685	1.711	1.738	
40	1.332	1.345	1.358	1.371	1.384	1.397	1.409	1.422	1.435	1.448	1.461	1.487	1.513	1.538	1.564	1.590	1.616	1.642	1.667	1.693	1.719	
42	1.316	1.329	1.341	1.353	1.365	1.378	1.390	1.402	1.415	1.427	1.439	1.464	1.488	1.513	1.537	1.562	1.587	1.611	1.636	1.660	1.685	
44	1.302	1.314	1.325	1.337	1.349	1.361	1.372	1.384	1.396	1.407	1.419	1.443	1.466	1.490	1.513	1.536	1.560	1.583	1.607	1.630	1.654	
46	1.289	1.300	1.311	1.322	1.334	1.345	1.356	1.367	1.379	1.390	1.401	1.423	1.446	1.468	1.491	1.513	1.536	1.558	1.580	1.603	1.625	
48	1.277	1.287	1.298	1.309	1.320	1.330	1.341	1.352	1.363	1.373	1.384	1.406	1.427	1.449	1.470	1.492	1.513	1.535	1.556	1.578	1.599	
50	1.266	1.276	1.286	1.297	1.307	1.317	1.328	1.338	1.348	1.359	1.369	1.390	1.410	1.431	1.451	1.472	1.493	1.513	1.534	1.555	1.575	
52	1.255	1.265	1.275	1.285	1.295	1.305	1.315	1.325	1.335	1.345	1.355	1.375	1.394	1.414	1.434	1.454	1.474	1.494	1.513	1.533	1.553	
54	1.246	1.256	1.265	1.275	1.284	1.294	1.303	1.313	1.322	1.342	1.361	1.380	1.399	1.418	1.437	1.456	1.475	1.494	1.514	1.533		
56	1.237	1.246	1.256	1.265	1.274	1.283	1.292	1.302	1.311	1.320	1.329	1.348	1.366	1.385	1.403	1.421	1.440	1.458	1.477	1.495	1.514	
58	1.229	1.238	1.247	1.256	1.265	1.273	1.282	1.291	1.300	1.309	1.318	1.336	1.354	1.371	1.389	1.407	1.425	1.443	1.460	1.478	1.496	
60	1.221	1.230	1.239	1.247	1.256	1.264	1.273	1.282	1.290	1.299	1.307	1.325	1.342	1.359	1.376	1.393	1.411	1.428	1.445	1.462	1.479	
65	1.204	1.212	1.220	1.228	1.236	1.244	1.252	1.260	1.268	1.276	1.284	1.300	1.316	1.331	1.347	1.363	1.379	1.395	1.411	1.427	1.443	
70	1.190	1.197	1.205	1.212	1.219	1.227	1.234	1.241	1.249	1.256	1.263	1.278	1.293	1.308	1.322	1.337	1.352	1.367	1.381	1.396	1.411	
75	1.177	1.184	1.191	1.198	1.205	1.212	1.218	1.225	1.232	1.239	1.246	1.260	1.273	1.287	1.301	1.315	1.328	1.342	1.356	1.370	1.384	

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 1

$$\frac{b_F}{b_W} = 0.3 - \text{Continued}$$

$$\frac{t_W}{t_S} = 0.79$$

b_W/t_W	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
b_S/t_S																					
25	1.808	1.840	1.873	1.905	1.938	1.970	2.003	2.035	2.068	2.100	2.133	2.197	2.262	2.327	2.392	2.457	2.522	2.587	2.652	2.717	2.782
26	1.777	1.808	1.839	1.871	1.902	1.933	1.964	1.995	2.027	2.058	2.089	2.151	2.214	2.276	2.339	2.401	2.463	2.526	2.588	2.651	2.713
27	1.748	1.778	1.808	1.838	1.868	1.898	1.928	1.958	1.989	2.019	2.049	2.109	2.169	2.229	2.289	2.349	2.409	2.469	2.529	2.590	2.650
28	1.721	1.750	1.779	1.808	1.837	1.866	1.895	1.924	1.953	1.982	2.011	2.069	2.127	2.185	2.243	2.301	2.359	2.417	2.475	2.533	2.590
29	1.697	1.725	1.752	1.780	1.808	1.836	1.864	1.892	1.920	1.948	1.976	2.032	2.088	2.144	2.200	2.256	2.312	2.368	2.420	2.480	2.546
30	1.673	1.700	1.727	1.754	1.781	1.809	1.836	1.863	1.890	1.917	1.944	1.998	2.052	2.106	2.160	2.214	2.268	2.322	2.376	2.431	2.485
31	1.652	1.678	1.704	1.730	1.756	1.782	1.809	1.835	1.861	1.887	1.913	1.966	2.018	2.070	2.123	2.175	2.227	2.280	2.332	2.384	2.437
32	1.631	1.657	1.682	1.707	1.733	1.758	1.783	1.809	1.834	1.859	1.885	1.935	1.986	2.037	2.088	2.138	2.189	2.240	2.290	2.341	2.392
33	1.612	1.637	1.661	1.686	1.710	1.735	1.760	1.784	1.809	1.833	1.858	1.907	1.956	2.006	2.055	2.104	2.153	2.202	2.251	2.301	2.350
34	1.594	1.618	1.642	1.666	1.690	1.713	1.737	1.761	1.785	1.809	1.833	1.880	1.928	1.976	2.024	2.071	2.119	2.167	2.215	2.262	2.310
35	1.577	1.600	1.623	1.647	1.670	1.693	1.716	1.739	1.763	1.786	1.809	1.855	1.902	1.948	1.994	2.041	2.087	2.133	2.180	2.226	2.273
36	1.561	1.584	1.606	1.629	1.651	1.674	1.696	1.719	1.741	1.764	1.786	1.832	1.877	1.922	1.967	2.012	2.057	2.102	2.147	2.192	1.237
37	1.546	1.568	1.590	1.612	1.634	1.656	1.677	1.699	1.721	1.743	1.765	1.809	1.853	1.897	1.941	1.984	2.028	2.072	2.116	2.160	2.204
38	1.532	1.553	1.574	1.596	1.617	1.638	1.660	1.681	1.702	1.724	1.745	1.788	1.830	1.873	1.916	1.959	2.001	2.044	2.087	2.129	2.172
39	1.518	1.539	1.560	1.580	1.601	1.622	1.643	1.664	1.684	1.705	1.726	1.768	1.809	1.851	1.892	1.934	1.976	2.017	2.059	2.100	2.142
40	1.505	1.525	1.546	1.566	1.586	1.606	1.627	1.647	1.667	1.688	1.708	1.748	1.789	1.830	1.870	1.911	1.951	1.992	2.032	2.073	2.114
42	1.481	1.500	1.520	1.539	1.558	1.578	1.597	1.616	1.635	1.655	1.674	1.713	1.751	1.790	1.829	1.867	1.906	1.945	1.983	2.022	2.060
44	1.459	1.478	1.496	1.511	1.533	1.551	1.570	1.588	1.607	1.626	1.643	1.680	1.717	1.754	1.791	1.828	1.865	1.902	1.938	1.975	2.012
46	1.439	1.457	1.474	1.492	1.510	1.527	1.545	1.563	1.580	1.598	1.615	1.651	1.686	1.721	1.757	1.792	1.827	1.862	1.898	1.933	1.968
48	1.421	1.438	1.455	1.472	1.488	1.505	1.522	1.539	1.556	1.573	1.590	1.621	1.657	1.691	1.725	1.759	1.793	1.826	1.860	1.894	1.928
50	1.404	1.420	1.436	1.453	1.469	1.485	1.501	1.518	1.534	1.550	1.566	1.599	1.631	1.664	1.696	1.729	1.761	1.793	1.826	1.858	1.891
52	1.388	1.404	1.420	1.435	1.451	1.466	1.482	1.498	1.513	1.529	1.544	1.576	1.607	1.638	1.669	1.700	1.732	1.763	1.794	1.825	1.857
54	1.374	1.389	1.404	1.419	1.434	1.449	1.464	1.479	1.494	1.509	1.524	1.554	1.584	1.614	1.645	1.675	1.705	1.735	1.765	1.795	1.825
56	1.361	1.375	1.390	1.404	1.419	1.433	1.448	1.462	1.477	1.491	1.506	1.535	1.564	1.593	1.621	1.650	1.679	1.708	1.737	1.766	1.795
58	1.348	1.362	1.376	1.390	1.404	1.418	1.432	1.446	1.460	1.474	1.488	1.516	1.544	1.572	1.600	1.628	1.656	1.684	1.712	1.740	1.768
60	1.337	1.350	1.364	1.377	1.391	1.404	1.418	1.431	1.445	1.458	1.472	1.499	1.526	1.553	1.580	1.607	1.634	1.661	1.688	1.715	1.742
65	1.311	1.323	1.336	1.348	1.361	1.373	1.386	1.398	1.411	1.423	1.436	1.461	1.486	1.510	1.535	1.560	1.585	1.610	1.635	1.660	1.686
70	1.289	1.300	1.312	1.323	1.335	1.347	1.358	1.370	1.381	1.393	1.404	1.428	1.451	1.474	1.497	1.520	1.544	1.567	1.590	1.613	1.636
75	1.269	1.280	1.291	1.302	1.313	1.323	1.334	1.345	1.356	1.367	1.377	1.399	1.421	1.442	1.464	1.486	1.507	1.529	1.551	1.572	1.594

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 1

$$\frac{b_F}{b_W} = 0.3 \sim \text{Concluded}$$

$$\frac{t_W}{t_3} = 1.00$$

b_W/t_W	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
b_S/t_3																					
25	2.247	2.299	2.351	2.403	2.455	2.506	2.559	2.611	2.663	2.715	2.767	2.871	2.975	3.079	3.183	3.287	3.291	3.495	3.599	3.703	3.807
26	2.199	2.249	2.299	2.349	2.399	2.449	2.499	2.549	2.599	2.649	2.699	2.799	2.899	2.999	3.099	3.199	3.299	3.399	3.499	3.599	3.699
27	2.154	2.202	2.251	2.299	2.347	2.395	2.443	2.491	2.540	2.588	2.636	2.732	2.828	2.925	3.021	3.117	3.211	3.310	3.406	3.502	3.599
28	2.113	2.160	2.206	2.252	2.299	2.345	2.392	2.438	2.485	2.531	2.577	2.670	2.763	2.856	2.949	3.042	3.135	3.227	3.320	3.413	3.506
29	2.075	2.120	2.164	2.209	2.254	2.299	2.344	2.389	2.433	2.478	2.523	2.613	2.702	2.792	2.882	2.971	3.061	3.151	3.240	3.330	3.420
30	2.039	2.082	2.126	2.169	2.212	2.256	2.299	2.342	2.386	2.429	2.472	2.559	2.646	2.732	2.819	2.906	2.992	3.079	3.166	3.252	3.339
31	2.005	2.047	2.089	2.131	2.173	2.215	2.257	2.299	2.341	2.383	2.425	2.509	2.592	2.676	2.760	2.844	2.928	3.012	3.096	3.180	3.263
32	1.974	2.015	2.055	2.096	2.136	2.177	2.218	2.258	2.299	2.340	2.380	2.461	2.513	2.624	2.705	2.786	2.868	2.949	3.030	3.111	3.193
33	1.944	1.984	2.023	2.063	2.102	2.141	2.181	2.220	2.260	2.299	2.338	2.417	2.496	2.575	2.654	2.732	2.811	2.890	2.969	3.048	3.126
34	1.917	1.955	1.993	2.031	2.070	2.078	2.114	2.154	2.223	2.261	2.299	2.376	2.452	2.528	2.605	2.681	2.758	2.834	2.911	2.987	3.064
35	1.890	1.928	1.965	2.002	2.039	2.076	2.113	2.150	2.188	2.225	2.262	2.336	2.410	2.485	2.559	2.633	2.708	2.782	2.856	2.930	3.005
36	1.866	1.902	1.938	1.974	2.010	2.046	2.082	2.119	2.155	2.191	2.227	2.299	2.371	2.444	2.516	2.588	2.660	2.732	2.805	2.877	2.949
37	1.842	1.877	1.913	1.948	1.983	2.018	2.053	2.088	2.123	2.159	2.194	2.264	2.334	2.405	2.475	2.545	2.615	2.686	2.756	2.826	2.896
38	1.820	1.854	1.889	1.923	1.957	1.991	2.025	2.060	2.094	2.128	2.162	2.231	2.299	2.368	2.436	2.504	2.573	2.641	2.710	2.778	2.847
39	1.799	1.832	1.866	1.899	1.932	1.966	1.999	2.033	2.066	2.099	2.133	2.199	2.266	2.333	2.399	2.466	2.533	2.599	2.666	2.733	2.799
40	1.779	1.812	1.844	1.877	1.909	1.942	1.974	2.007	2.039	2.072	2.104	2.169	2.234	2.299	2.364	2.429	2.494	2.559	2.624	2.689	2.754
42	1.742	1.773	1.804	1.835	1.866	1.897	1.928	1.959	1.990	2.021	2.052	2.114	2.175	2.237	2.299	2.361	2.423	2.485	2.547	2.609	2.671
44	1.708	1.738	1.767	1.797	1.826	1.856	1.886	1.915	1.945	1.974	2.004	2.063	2.122	2.181	2.240	2.299	2.358	2.417	2.477	2.536	2.595
46	1.678	1.706	1.734	1.762	1.791	1.819	1.847	1.875	1.904	1.932	1.960	2.017	2.073	2.130	2.186	2.243	2.299	2.356	2.412	2.469	2.525
48	1.649	1.676	1.703	1.731	1.758	1.785	1.812	1.839	1.866	1.893	1.920	1.974	2.028	2.083	2.137	2.191	2.245	2.299	2.353	2.408	2.462
50	1.623	1.649	1.675	1.701	1.727	1.753	1.779	1.805	1.831	1.857	1.883	1.935	1.987	2.039	2.091	2.143	2.195	2.247	2.299	2.351	2.403
52	1.599	1.624	1.649	1.674	1.699	1.724	1.749	1.774	1.799	1.824	1.849	1.899	1.949	1.999	2.049	2.099	2.149	2.199	2.249	2.299	2.349
54	1.577	1.601	1.625	1.649	1.673	1.698	1.722	1.746	1.770	1.794	1.818	1.866	1.911	1.962	2.011	2.059	2.107	2.155	2.203	2.251	2.299
56	1.557	1.580	1.603	1.626	1.649	1.673	1.696	1.719	1.742	1.765	1.789	1.835	1.882	1.928	1.974	2.021	2.067	2.114	2.160	2.207	2.253
58	1.537	1.560	1.582	1.605	1.627	1.649	1.672	1.694	1.717	1.739	1.761	1.808	1.851	1.894	1.941	1.986	2.030	2.075	2.120	2.165	2.210
60	1.519	1.541	1.563	1.584	1.606	1.628	1.649	1.671	1.693	1.714	1.736	1.779	1.823	1.866	1.909	1.953	1.996	2.040	2.083	2.126	2.170
65	1.479	1.499	1.519	1.539	1.559	1.579	1.599	1.619	1.639	1.659	1.679	1.719	1.760	1.800	1.840	1.880	1.920	1.960	2.000	2.040	2.080
70	1.445	1.464	1.482	1.501	1.520	1.538	1.557	1.575	1.594	1.612	1.631	1.666	1.705	1.742	1.780	1.817	1.854	1.891	1.928	1.965	2.002
75	1.416	1.433	1.450	1.468	1.485	1.502	1.520	1.537	1.554	1.572	1.589	1.624	1.658	1.693	1.728	1.762	1.797	1.832	1.866	1.901	1.936

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 2

VALUES OF A_1/t_s FOR FLAT PANELS WITH Z-SECTION STIFFENERS. $\frac{b_p}{t_s} = 0.4$.

$$\frac{A_1}{t_s} = 1 + \left[\frac{\frac{b_w}{t_s} \left(1 + \frac{b_p}{b_w} \right) + \frac{b_A}{t_s} - \left(2 - \frac{\pi}{2} \right) \left(\frac{r_A}{t_w} + \frac{r_p}{t_w} + 1 \right)}{b_s/t_s} \left(\frac{t_w}{t_s} \right)^2 \right]$$

$$\frac{t_w}{t_s} = 0.51$$

b_w/t_w	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
b_s/t_s																					
25	1.374	1.389	1.403	1.418	1.432	1.447	1.462	1.476	1.491	1.505	1.520	1.549	1.578	1.607	1.636	1.665	1.695	1.724	1.753	1.782	1.811
26	1.360	1.374	1.388	1.402	1.416	1.430	1.444	1.458	1.472	1.486	1.500	1.528	1.556	1.584	1.612	1.640	1.668	1.696	1.724	1.752	1.780
27	1.346	1.360	1.373	1.387	1.400	1.414	1.427	1.441	1.455	1.468	1.481	1.508	1.535	1.562	1.589	1.616	1.643	1.670	1.697	1.724	1.751
28	1.334	1.347	1.360	1.373	1.386	1.399	1.412	1.425	1.438	1.451	1.464	1.490	1.516	1.542	1.568	1.594	1.620	1.646	1.672	1.698	1.724
29	1.323	1.335	1.348	1.360	1.373	1.385	1.398	1.410	1.423	1.436	1.448	1.473	1.498	1.523	1.549	1.574	1.599	1.624	1.649	1.674	1.699
30	1.312	1.324	1.336	1.348	1.360	1.373	1.385	1.397	1.409	1.421	1.433	1.457	1.482	1.506	1.530	1.555	1.579	1.603	1.627	1.652	1.676
31	1.302	1.313	1.325	1.337	1.349	1.360	1.372	1.384	1.396	1.407	1.419	1.443	1.466	1.490	1.513	1.537	1.560	1.584	1.607	1.631	1.654
32	1.292	1.304	1.315	1.326	1.338	1.349	1.361	1.374	1.383	1.395	1.406	1.429	1.452	1.474	1.497	1.520	1.543	1.565	1.588	1.611	1.634
33	1.283	1.294	1.306	1.317	1.328	1.339	1.350	1.361	1.372	1.383	1.394	1.416	1.438	1.460	1.482	1.504	1.526	1.548	1.570	1.592	1.614
34	1.275	1.286	1.297	1.307	1.318	1.329	1.339	1.350	1.361	1.372	1.382	1.404	1.425	1.446	1.468	1.489	1.511	1.532	1.554	1.575	1.596
35	1.267	1.278	1.288	1.298	1.309	1.319	1.330	1.340	1.350	1.361	1.371	1.392	1.413	1.434	1.455	1.475	1.496	1.517	1.538	1.559	1.579
36	1.260	1.270	1.280	1.290	1.300	1.310	1.321	1.331	1.341	1.351	1.361	1.381	1.401	1.422	1.442	1.462	1.482	1.503	1.523	1.543	1.563
37	1.253	1.263	1.272	1.282	1.292	1.302	1.312	1.322	1.332	1.341	1.351	1.371	1.391	1.410	1.430	1.450	1.469	1.489	1.509	1.528	1.548
38	1.246	1.256	1.265	1.275	1.285	1.294	1.304	1.313	1.323	1.332	1.342	1.361	1.380	1.399	1.419	1.438	1.457	1.476	1.495	1.514	1.534
39	1.240	1.249	1.259	1.268	1.277	1.287	1.296	1.305	1.315	1.324	1.333	1.352	1.371	1.389	1.408	1.427	1.445	1.464	1.483	1.501	1.520
40	1.234	1.243	1.252	1.261	1.270	1.279	1.288	1.298	1.307	1.316	1.325	1.343	1.361	1.380	1.398	1.416	1.434	1.452	1.471	1.489	1.507
42	1.223	1.231	1.240	1.249	1.257	1.266	1.275	1.283	1.292	1.301	1.309	1.327	1.344	1.361	1.379	1.396	1.413	1.431	1.448	1.465	1.483
44	1.213	1.221	1.229	1.237	1.246	1.254	1.262	1.271	1.279	1.287	1.295	1.312	1.328	1.345	1.362	1.378	1.395	1.411	1.428	1.444	1.461
46	1.203	1.211	1.219	1.227	1.235	1.243	1.251	1.259	1.267	1.275	1.283	1.298	1.314	1.330	1.346	1.362	1.377	1.393	1.409	1.425	1.441
48	1.195	1.202	1.210	1.218	1.225	1.233	1.240	1.248	1.256	1.263	1.271	1.286	1.301	1.316	1.331	1.347	1.362	1.377	1.392	1.407	1.422
50	1.187	1.194	1.202	1.209	1.216	1.224	1.231	1.238	1.245	1.253	1.260	1.274	1.289	1.304	1.318	1.333	1.347	1.362	1.376	1.391	1.406
52	1.180	1.187	1.194	1.201	1.208	1.215	1.222	1.229	1.236	1.243	1.250	1.264	1.278	1.292	1.306	1.320	1.334	1.348	1.362	1.376	1.390
54	1.173	1.180	1.187	1.193	1.200	1.207	1.214	1.220	1.227	1.234	1.241	1.254	1.268	1.281	1.295	1.308	1.322	1.335	1.349	1.362	1.376
56	1.167	1.174	1.180	1.187	1.193	1.200	1.206	1.213	1.219	1.226	1.232	1.245	1.258	1.271	1.284	1.297	1.310	1.323	1.336	1.349	1.362
58	1.161	1.168	1.174	1.180	1.186	1.193	1.199	1.205	1.212	1.218	1.224	1.237	1.249	1.262	1.274	1.287	1.299	1.312	1.324	1.337	1.350
60	1.156	1.162	1.168	1.174	1.180	1.186	1.192	1.198	1.204	1.211	1.217	1.229	1.241	1.253	1.264	1.277	1.289	1.302	1.314	1.326	1.338
65	1.144	1.150	1.155	1.161	1.166	1.172	1.178	1.183	1.189	1.194	1.200	1.211	1.222	1.234	1.245	1.256	1.267	1.278	1.290	1.301	1.312
70	1.134	1.139	1.144	1.149	1.154	1.160	1.165	1.170	1.175	1.180	1.186	1.196	1.206	1.217	1.227	1.238	1.248	1.258	1.269	1.279	1.290
75	1.125	1.130	1.134	1.139	1.144	1.149	1.154	1.159	1.164	1.168	1.173	1.183	1.193	1.202	1.212	1.222	1.232	1.241	1.251	1.261	1.270

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 2

 $\frac{b_p}{b_w} = 0.4$ - Continued

 $\frac{t_w}{t_s} = 0.63$

b_w/t_w	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
b_s/t_s																					
25	1.563	1.585	1.608	1.630	1.652	1.674	1.696	1.719	1.741	1.763	1.785	1.800	1.819	1.963	2.008	2.052	2.097	2.141	2.186	2.230	
26	1.541	1.563	1.584	1.606	1.627	1.648	1.670	1.691	1.712	1.734	1.755	1.798	1.811	1.883	1.926	1.969	2.012	2.054	2.097	2.140	2.183
27	1.521	1.542	1.563	1.583	1.604	1.624	1.645	1.665	1.686	1.707	1.727	1.768	1.810	1.851	1.892	1.933	1.974	2.015	2.057	2.098	2.139
28	1.503	1.523	1.542	1.562	1.582	1.602	1.622	1.642	1.662	1.681	1.701	1.741	1.781	1.820	1.860	1.900	1.939	1.979	2.019	2.059	2.098
29	1.485	1.505	1.524	1.543	1.562	1.583	1.600	1.620	1.639	1.658	1.677	1.715	1.754	1.792	1.830	1.869	1.907	1.945	1.984	2.022	2.060
30	1.469	1.488	1.506	1.525	1.543	1.562	1.580	1.599	1.617	1.636	1.654	1.692	1.729	1.766	1.803	1.840	1.877	1.914	1.951	1.988	2.025
31	1.454	1.472	1.490	1.508	1.526	1.544	1.562	1.580	1.598	1.615	1.633	1.669	1.705	1.741	1.777	1.813	1.848	1.884	1.920	1.956	1.992
32	1.440	1.457	1.475	1.492	1.509	1.527	1.544	1.561	1.579	1.596	1.614	1.648	1.683	1.718	1.753	1.787	1.822	1.857	1.891	1.926	1.961
33	1.427	1.445	1.460	1.477	1.494	1.511	1.528	1.544	1.561	1.578	1.595	1.629	1.662	1.696	1.730	1.763	1.797	1.831	1.864	1.898	1.932
34	1.414	1.430	1.447	1.463	1.479	1.496	1.512	1.528	1.545	1.561	1.577	1.610	1.643	1.676	1.708	1.741	1.774	1.806	1.839	1.872	1.904
35	1.402	1.418	1.434	1.450	1.466	1.482	1.497	1.513	1.530	1.545	1.561	1.593	1.624	1.656	1.688	1.720	1.752	1.783	1.815	1.847	1.879
36	1.391	1.406	1.422	1.437	1.453	1.468	1.484	1.499	1.515	1.530	1.545	1.576	1.607	1.638	1.669	1.700	1.731	1.762	1.792	1.823	1.854
37	1.380	1.395	1.411	1.426	1.441	1.456	1.473	1.486	1.501	1.516	1.531	1.561	1.591	1.621	1.651	1.681	1.711	1.741	1.771	1.801	1.831
38	1.370	1.385	1.400	1.414	1.429	1.444	1.458	1.473	1.487	1.502	1.517	1.546	1.575	1.604	1.634	1.663	1.692	1.721	1.751	1.780	1.809
39	1.361	1.373	1.389	1.404	1.418	1.432	1.446	1.461	1.475	1.489	1.503	1.532	1.560	1.589	1.617	1.646	1.674	1.703	1.731	1.760	1.788
40	1.352	1.366	1.380	1.394	1.408	1.421	1.435	1.449	1.463	1.477	1.491	1.519	1.546	1.574	1.602	1.630	1.658	1.685	1.713	1.741	1.769
42	1.335	1.348	1.362	1.375	1.388	1.401	1.415	1.428	1.441	1.454	1.467	1.494	1.520	1.547	1.573	1.600	1.626	1.653	1.679	1.706	1.732
44	1.320	1.333	1.345	1.358	1.370	1.383	1.396	1.408	1.421	1.434	1.446	1.471	1.497	1.522	1.547	1.573	1.598	1.623	1.648	1.674	1.699
46	1.306	1.318	1.330	1.342	1.354	1.366	1.379	1.391	1.403	1.415	1.427	1.451	1.475	1.499	1.523	1.548	1.572	1.596	1.620	1.644	1.668
48	1.293	1.305	1.316	1.328	1.340	1.351	1.363	1.377	1.386	1.397	1.409	1.432	1.455	1.479	1.502	1.525	1.548	1.571	1.594	1.617	1.641
50	1.282	1.293	1.304	1.315	1.326	1.337	1.348	1.359	1.370	1.382	1.393	1.415	1.437	1.459	1.482	1.504	1.526	1.548	1.571	1.593	1.615
52	1.271	1.281	1.292	1.303	1.313	1.324	1.335	1.346	1.356	1.367	1.378	1.399	1.420	1.442	1.463	1.484	1.506	1.527	1.549	1.570	1.591
54	1.261	1.271	1.281	1.292	1.302	1.312	1.322	1.333	1.343	1.353	1.364	1.384	1.405	1.425	1.446	1.467	1.487	1.508	1.528	1.549	1.569
56	1.251	1.261	1.271	1.281	1.291	1.301	1.311	1.321	1.331	1.341	1.351	1.370	1.390	1.410	1.430	1.450	1.470	1.490	1.509	1.529	1.549
58	1.243	1.252	1.262	1.271	1.281	1.291	1.300	1.310	1.319	1.329	1.339	1.358	1.377	1.396	1.415	1.434	1.453	1.473	1.492	1.511	1.530
60	1.235	1.244	1.253	1.262	1.272	1.281	1.290	1.299	1.309	1.318	1.327	1.346	1.364	1.383	1.401	1.420	1.438	1.457	1.475	1.494	1.512
65	1.217	1.225	1.234	1.242	1.251	1.259	1.268	1.276	1.285	1.294	1.302	1.319	1.336	1.353	1.370	1.388	1.405	1.422	1.439	1.456	1.473
70	1.201	1.209	1.217	1.225	1.233	1.241	1.249	1.257	1.265	1.273	1.280	1.296	1.312	1.328	1.344	1.360	1.376	1.392	1.408	1.423	1.439
75	1.188	1.195	1.203	1.210	1.217	1.225	1.232	1.240	1.247	1.254	1.262	1.277	1.291	1.306	1.321	1.336	1.351	1.366	1.380	1.395	1.410

 NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 2

$$\frac{b_p}{b_w} = 0.4 - \text{Continued}$$

$$\frac{t_w}{t_s} = 0.79$$

b_w/t_w	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
b_s/t_s																					
25	1.858	1.893	1.928	1.963	1.998	2.033	2.068	2.103	2.138	2.172	2.207	2.277	2.347	2.417	2.487	2.557	2.627	2.697	2.767	2.836	2.906
26	1.825	1.859	1.892	1.926	1.959	1.993	2.027	2.060	2.094	2.127	2.161	2.228	2.295	2.363	2.430	2.497	2.561	2.631	2.699	2.766	2.833
27	1.794	1.827	1.859	1.891	1.924	1.956	1.989	2.021	2.053	2.086	2.118	2.183	2.247	2.312	2.377	2.442	2.506	2.571	2.636	2.700	2.765
28	1.766	1.797	1.828	1.860	1.891	1.922	1.953	1.984	2.016	2.047	2.078	2.140	2.203	2.265	2.328	2.390	2.453	2.515	2.577	2.640	2.702
29	1.740	1.770	1.800	1.830	1.860	1.890	1.920	1.950	1.981	2.011	2.041	2.101	2.161	2.222	2.282	2.342	2.402	2.463	2.523	2.583	2.643
30	1.715	1.744	1.773	1.802	1.831	1.861	1.890	1.919	1.948	1.977	2.006	2.064	2.123	2.181	2.239	2.297	2.356	2.414	2.472	2.530	2.599
31	1.692	1.720	1.748	1.776	1.805	1.833	1.861	1.889	1.917	1.946	1.974	2.030	2.086	2.143	2.199	2.256	2.312	2.368	2.425	2.481	2.537
32	1.670	1.698	1.725	1.752	1.779	1.807	1.834	1.861	1.889	1.916	1.943	1.998	2.053	2.107	2.162	2.216	2.271	2.326	2.380	2.435	2.489
33	1.650	1.676	1.703	1.729	1.756	1.782	1.809	1.835	1.862	1.888	1.915	1.968	2.021	2.074	2.127	2.179	2.232	2.285	2.338	2.391	2.444
34	1.631	1.657	1.682	1.708	1.734	1.759	1.785	1.811	1.836	1.862	1.888	1.939	1.991	2.042	2.093	2.145	2.196	2.248	2.299	2.350	2.402
35	1.613	1.638	1.663	1.688	1.713	1.738	1.763	1.788	1.812	1.837	1.862	1.912	1.962	2.012	2.062	2.112	2.162	2.212	2.262	2.312	2.362
36	1.596	1.620	1.644	1.669	1.693	1.717	1.741	1.766	1.790	1.814	1.838	1.887	1.936	1.984	2.033	2.081	2.130	2.178	2.227	2.275	2.321
37	1.580	1.603	1.627	1.650	1.674	1.698	1.721	1.745	1.769	1.792	1.816	1.863	1.910	1.957	2.005	2.052	2.099	2.146	2.194	2.241	2.288
38	1.564	1.587	1.610	1.633	1.656	1.679	1.702	1.725	1.748	1.771	1.794	1.840	1.886	1.932	1.978	2.024	2.070	2.116	2.162	2.208	2.254
39	1.550	1.572	1.595	1.617	1.640	1.662	1.684	1.707	1.729	1.752	1.774	1.819	1.864	1.908	1.953	1.998	2.043	2.088	2.132	2.177	2.222
40	1.536	1.558	1.580	1.602	1.624	1.645	1.667	1.689	1.711	1.733	1.755	1.798	1.842	1.886	1.929	1.973	2.017	2.060	2.104	2.148	2.192
42	1.511	1.531	1.552	1.573	1.594	1.615	1.635	1.656	1.677	1.698	1.719	1.760	1.802	1.844	1.885	1.927	1.968	2.010	2.052	2.093	2.135
44	1.487	1.507	1.527	1.547	1.567	1.587	1.607	1.626	1.646	1.666	1.686	1.726	1.765	1.805	1.845	1.885	1.924	1.964	2.004	2.043	2.083
46	1.466	1.485	1.504	1.523	1.542	1.561	1.580	1.599	1.618	1.637	1.656	1.694	1.732	1.770	1.808	1.846	1.884	1.922	1.960	1.998	2.036
48	1.447	1.465	1.483	1.501	1.520	1.538	1.556	1.574	1.592	1.611	1.629	1.665	1.702	1.738	1.774	1.811	1.847	1.884	1.920	1.956	1.993
50	1.429	1.446	1.464	1.481	1.499	1.516	1.534	1.551	1.569	1.586	1.604	1.639	1.674	1.709	1.743	1.778	1.813	1.848	1.883	1.918	1.953
52	1.412	1.429	1.446	1.463	1.480	1.496	1.513	1.530	1.547	1.564	1.580	1.614	1.648	1.681	1.715	1.748	1.782	1.816	1.849	1.883	1.917
54	1.397	1.413	1.430	1.446	1.462	1.478	1.494	1.510	1.527	1.543	1.559	1.591	1.624	1.656	1.688	1.721	1.753	1.786	1.818	1.850	1.883
56	1.383	1.399	1.414	1.430	1.445	1.461	1.477	1.492	1.508	1.523	1.539	1.570	1.601	1.633	1.664	1.695	1.726	1.757	1.789	1.820	1.851
58	1.370	1.385	1.400	1.415	1.430	1.445	1.460	1.475	1.490	1.505	1.520	1.551	1.581	1.611	1.641	1.671	1.701	1.731	1.761	1.792	1.822
60	1.357	1.372	1.387	1.401	1.416	1.430	1.445	1.459	1.474	1.489	1.503	1.532	1.561	1.590	1.620	1.649	1.678	1.707	1.736	1.765	1.794
65	1.330	1.343	1.357	1.370	1.384	1.397	1.411	1.424	1.438	1.451	1.464	1.491	1.518	1.545	1.572	1.599	1.626	1.653	1.679	1.706	1.733
70	1.306	1.319	1.331	1.344	1.356	1.369	1.381	1.394	1.406	1.419	1.431	1.456	1.481	1.506	1.531	1.556	1.581	1.606	1.631	1.656	1.681
75	1.286	1.298	1.309	1.321	1.333	1.344	1.356	1.368	1.379	1.391	1.402	1.426	1.449	1.472	1.496	1.519	1.542	1.566	1.589	1.612	1.635

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 2
 $\frac{b_F}{b_W} = 0.4$ - Concluded

$$\frac{t_W}{t_S} = 1.00$$

b_W/t_S	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
25	2.327	2.383	2.439	2.495	2.551	2.607	2.663	2.719	2.775	2.831	2.887	2.999	3.111	3.223	3.335	3.447	3.559	3.671	3.783	3.895	4.007
26	2.276	2.330	2.383	2.437	2.491	2.545	2.599	2.653	2.706	2.760	2.814	2.922	3.030	3.157	3.245	3.353	3.460	3.568	3.676	3.783	3.891
27	2.228	2.280	2.332	2.384	2.436	2.488	2.540	2.591	2.643	2.695	2.747	2.851	2.954	3.058	3.162	3.265	3.369	3.473	3.577	3.680	3.784
28	2.185	2.235	2.285	2.335	2.385	2.435	2.485	2.535	2.585	2.635	2.685	2.785	2.885	2.985	3.085	3.185	3.285	3.385	3.485	3.585	3.685
29	2.144	2.192	2.240	2.289	2.337	2.385	2.433	2.482	2.530	2.578	2.626	2.723	2.820	2.916	3.013	3.109	3.206	3.302	3.399	3.495	3.592
30	2.106	2.152	2.199	2.246	2.292	2.339	2.386	2.432	2.479	2.526	2.572	2.666	2.759	2.852	2.946	3.039	3.132	3.226	3.319	3.412	3.506
31	2.070	2.115	2.160	2.205	2.251	2.296	2.341	2.386	2.432	2.476	2.522	2.612	2.702	2.792	2.883	2.973	3.063	3.154	3.244	3.334	3.425
32	2.036	2.080	2.124	2.168	2.211	2.255	2.299	2.343	2.386	2.430	2.474	2.561	2.649	2.736	2.824	2.911	2.999	3.086	3.174	3.261	3.349
33	2.005	2.048	2.090	2.132	2.175	2.217	2.260	2.302	2.344	2.387	2.429	2.514	2.599	2.684	2.769	2.854	2.938	3.023	3.108	3.193	3.278
34	1.975	2.017	2.058	2.099	2.140	2.181	2.223	2.264	2.305	2.346	2.387	2.470	2.552	2.641	2.717	2.799	2.881	2.961	3.046	3.128	3.211
35	1.948	1.988	2.028	2.068	2.108	2.148	2.188	2.228	2.268	2.308	2.348	2.428	2.508	2.588	2.668	2.748	2.828	2.908	2.988	3.068	3.148
36	1.921	1.960	1.999	2.038	2.077	2.116	2.155	2.194	2.232	2.271	2.310	2.388	2.466	2.544	2.621	2.699	2.777	2.855	2.932	3.010	3.088
37	1.896	1.934	1.972	2.010	2.048	2.086	2.123	2.161	2.199	2.237	2.275	2.350	2.426	2.502	2.578	2.653	2.729	2.805	2.880	2.956	3.032
38	1.873	1.910	1.946	1.983	2.020	2.057	2.094	2.131	2.168	2.204	2.241	2.315	2.389	2.462	2.536	2.610	2.683	2.757	2.831	2.904	2.978
39	1.850	1.886	1.922	1.958	1.994	2.030	2.066	2.102	2.138	2.174	2.209	2.281	2.355	2.425	2.497	2.568	2.640	2.712	2.784	2.856	2.927
40	1.829	1.864	1.899	1.934	1.969	2.004	2.039	2.074	2.109	2.144	2.179	2.249	2.319	2.389	2.459	2.529	2.599	2.669	2.739	2.809	2.879
42	1.790	1.823	1.856	1.890	1.923	1.956	1.990	2.023	2.056	2.090	2.123	2.190	2.256	2.323	2.390	2.456	2.523	2.590	2.656	2.723	2.790
44	1.754	1.786	1.817	1.849	1.881	1.913	1.945	1.976	2.008	2.040	2.072	2.136	2.199	2.263	2.327	2.390	2.454	2.517	2.581	2.645	2.708
46	1.721	1.751	1.782	1.812	1.843	1.873	1.904	1.934	1.961	1.995	2.025	2.086	2.147	2.208	2.269	2.330	2.391	2.451	2.512	2.573	2.634
48	1.691	1.720	1.749	1.778	1.808	1.837	1.866	1.895	1.924	1.953	1.983	2.041	2.099	2.158	2.216	2.274	2.333	2.391	2.449	2.508	2.566
50	1.663	1.691	1.719	1.747	1.775	1.803	1.831	1.859	1.887	1.915	1.943	1.999	2.055	2.111	2.167	2.223	2.279	2.335	2.391	2.447	2.503
52	1.638	1.665	1.692	1.719	1.746	1.772	1.799	1.826	1.853	1.880	1.907	1.961	2.015	2.069	2.122	2.176	2.230	2.284	2.338	2.392	2.446
54	1.614	1.640	1.666	1.692	1.718	1.744	1.770	1.796	1.822	1.848	1.873	1.925	1.977	2.029	2.081	2.133	2.185	2.236	2.288	2.340	2.392
56	1.592	1.617	1.642	1.667	1.692	1.717	1.742	1.767	1.792	1.817	1.842	1.892	1.942	2.042	2.092	2.142	2.192	2.242	2.292	2.342	
58	1.572	1.596	1.620	1.644	1.668	1.693	1.717	1.741	1.765	1.789	1.813	1.861	1.910	1.958	2.006	2.055	2.103	2.151	2.199	2.248	2.296
60	1.553	1.576	1.599	1.623	1.646	1.669	1.693	1.716	1.739	1.763	1.786	1.833	1.879	1.926	1.973	2.020	2.066	2.113	2.160	2.206	2.253
65	1.510	1.532	1.553	1.575	1.596	1.618	1.639	1.661	1.683	1.704	1.726	1.769	1.812	1.855	1.898	1.941	1.984	2.027	2.070	2.113	2.156
70	1.474	1.494	1.514	1.534	1.554	1.574	1.594	1.614	1.634	1.654	1.674	1.714	1.754	1.794	1.834	1.874	1.914	1.954	1.994	2.034	2.074
75	1.442	1.461	1.480	1.498	1.517	1.536	1.554	1.573	1.592	1.610	1.629	1.666	1.704	1.741	1.778	1.816	1.853	1.890	1.928	1.965	2.002

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 3

VALUES OF A_1/t_3 FOR FLAT PANELS WITH Z-SECTION STIFFENERS. $\frac{b_p}{b_w} = 0.5$.

$$\frac{A_1}{t_3} = 1 + \left[\frac{\frac{b_w}{t_3} \left(1 + \frac{b_p}{b_w} \right) + \frac{b_A}{t_3} - \left(2 - \frac{\pi}{2} \right) \left(\frac{r_A}{b_w} + \frac{r_p}{b_w} + 1 \right)}{b_3/t_3} \left(\frac{t_w}{t_3} \right)^2 \right]$$

$$\frac{t_w}{t_3} = 0.51$$

b_w/t_w	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
b_3/t_3																					
25	1.395	1.411	1.426	1.442	1.457	1.473	1.489	1.504	1.520	1.535	1.551	1.582	1.613	1.645	1.676	1.707	1.738	1.769	1.801	1.832	1.863
26	1.380	1.395	1.410	1.425	1.440	1.455	1.470	1.485	1.500	1.515	1.530	1.560	1.590	1.620	1.650	1.680	1.710	1.740	1.770	1.800	1.830
27	1.366	1.380	1.395	1.409	1.424	1.438	1.452	1.467	1.481	1.496	1.510	1.539	1.568	1.597	1.626	1.655	1.684	1.712	1.741	1.770	1.799
28	1.353	1.367	1.381	1.394	1.408	1.422	1.436	1.450	1.464	1.478	1.492	1.520	1.548	1.576	1.603	1.631	1.659	1.687	1.715	1.743	1.771
29	1.340	1.354	1.367	1.381	1.394	1.408	1.421	1.435	1.448	1.462	1.475	1.502	1.529	1.556	1.583	1.610	1.636	1.663	1.690	1.717	1.744
30	1.329	1.342	1.355	1.368	1.381	1.394	1.407	1.420	1.433	1.446	1.459	1.485	1.511	1.537	1.563	1.589	1.615	1.641	1.667	1.693	1.719
31	1.319	1.331	1.344	1.356	1.369	1.381	1.394	1.407	1.419	1.432	1.444	1.470	1.495	1.520	1.545	1.570	1.595	1.621	1.646	1.671	1.696
32	1.309	1.321	1.333	1.345	1.357	1.370	1.382	1.394	1.406	1.418	1.430	1.455	1.479	1.504	1.528	1.552	1.577	1.601	1.626	1.650	1.674
33	1.299	1.311	1.323	1.335	1.347	1.358	1.370	1.382	1.394	1.406	1.417	1.441	1.465	1.488	1.512	1.536	1.559	1.583	1.607	1.630	1.654
34	1.290	1.302	1.313	1.325	1.336	1.348	1.359	1.371	1.382	1.394	1.405	1.428	1.451	1.474	1.497	1.520	1.543	1.566	1.589	1.612	1.639
35	1.282	1.293	1.304	1.316	1.327	1.338	1.349	1.360	1.371	1.382	1.394	1.416	1.438	1.460	1.483	1.505	1.527	1.550	1.572	1.594	1.616
36	1.274	1.285	1.296	1.307	1.318	1.328	1.339	1.350	1.361	1.372	1.383	1.404	1.426	1.448	1.469	1.491	1.513	1.534	1.556	1.578	1.599
37	1.267	1.277	1.288	1.298	1.309	1.320	1.330	1.341	1.351	1.362	1.372	1.393	1.414	1.436	1.457	1.478	1.499	1.520	1.541	1.562	1.583
38	1.260	1.270	1.280	1.291	1.301	1.311	1.321	1.332	1.342	1.352	1.363	1.383	1.404	1.424	1.445	1.465	1.486	1.506	1.527	1.547	1.568
39	1.253	1.263	1.273	1.283	1.293	1.303	1.313	1.323	1.333	1.343	1.353	1.373	1.393	1.413	1.433	1.453	1.473	1.493	1.513	1.533	1.553
40	1.247	1.257	1.266	1.276	1.286	1.296	1.305	1.315	1.325	1.335	1.344	1.364	1.383	1.403	1.422	1.441	1.461	1.481	1.500	1.520	1.539
42	1.235	1.244	1.254	1.263	1.272	1.282	1.291	1.300	1.319	1.328	1.347	1.365	1.384	1.402	1.421	1.439	1.458	1.477	1.495	1.514	
44	1.224	1.233	1.242	1.251	1.260	1.269	1.278	1.286	1.295	1.304	1.313	1.331	1.349	1.366	1.384	1.402	1.419	1.437	1.455	1.473	1.490
46	1.215	1.223	1.232	1.240	1.249	1.257	1.266	1.274	1.283	1.291	1.299	1.316	1.333	1.350	1.367	1.384	1.401	1.418	1.435	1.452	1.469
48	1.206	1.214	1.222	1.230	1.238	1.246	1.254	1.263	1.271	1.279	1.287	1.303	1.319	1.336	1.352	1.368	1.384	1.401	1.417	1.433	1.450
50	1.197	1.205	1.213	1.221	1.229	1.237	1.244	1.252	1.260	1.268	1.276	1.291	1.307	1.322	1.338	1.354	1.369	1.385	1.400	1.416	1.432
52	1.190	1.197	1.205	1.212	1.220	1.227	1.235	1.242	1.250	1.257	1.265	1.280	1.295	1.310	1.325	1.340	1.355	1.370	1.385	1.400	1.415
54	1.183	1.190	1.197	1.205	1.212	1.219	1.226	1.233	1.241	1.248	1.255	1.270	1.284	1.298	1.313	1.327	1.342	1.356	1.371	1.385	1.400
56	1.176	1.183	1.190	1.197	1.204	1.211	1.218	1.225	1.232	1.239	1.246	1.260	1.274	1.288	1.302	1.316	1.330	1.344	1.357	1.371	1.385
58	1.170	1.177	1.184	1.190	1.197	1.204	1.211	1.217	1.224	1.231	1.237	1.251	1.264	1.278	1.291	1.305	1.318	1.332	1.345	1.359	1.372
60	1.165	1.171	1.178	1.184	1.191	1.197	1.204	1.210	1.217	1.223	1.230	1.243	1.256	1.269	1.282	1.295	1.308	1.321	1.334	1.347	1.360
65	1.152	1.158	1.164	1.170	1.176	1.182	1.188	1.194	1.200	1.206	1.212	1.224	1.236	1.248	1.260	1.272	1.284	1.296	1.308	1.320	1.332
70	1.141	1.147	1.152	1.158	1.163	1.169	1.175	1.180	1.186	1.191	1.197	1.208	1.219	1.230	1.241	1.253	1.264	1.275	1.286	1.297	1.308
75	1.132	1.137	1.142	1.147	1.152	1.158	1.163	1.168	1.173	1.178	1.184	1.194	1.204	1.215	1.225	1.236	1.246	1.256	1.267	1.277	1.288

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 3

 $\frac{b_F}{b_W} = 0.5 - \text{Continued}$
 $\frac{t_W}{t_S} = 0.63$

b_S/t_S	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
25	1.595	1.619	1.642	1.666	1.690	1.714	1.738	1.762	1.785	1.809	1.833	1.881	1.928	1.976	2.024	2.071	2.119	2.166	2.214	2.262	2.309
26	1.572	1.595	1.618	1.641	1.664	1.686	1.709	1.732	1.755	1.778	1.810	1.847	1.893	1.958	1.984	2.030	2.076	2.122	2.167	2.213	2.259
27	1.551	1.573	1.595	1.617	1.639	1.661	1.683	1.705	1.727	1.749	1.771	1.815	1.860	1.904	1.948	1.992	2.036	2.080	2.124	2.168	2.212
28	1.531	1.552	1.574	1.595	1.616	1.637	1.659	1.680	1.701	1.722	1.744	1.786	1.829	1.871	1.914	1.956	1.999	2.042	2.084	2.127	2.169
29	1.513	1.533	1.554	1.574	1.595	1.615	1.636	1.657	1.677	1.698	1.718	1.759	1.800	1.841	1.882	1.923	1.964	2.006	2.047	2.088	2.129
30	1.496	1.516	1.535	1.555	1.575	1.595	1.615	1.635	1.654	1.674	1.694	1.734	1.774	1.813	1.853	1.893	1.932	1.972	2.012	2.051	2.091
31	1.480	1.499	1.518	1.537	1.557	1.576	1.595	1.614	1.635	1.653	1.672	1.710	1.749	1.787	1.825	1.864	1.902	1.941	1.979	2.018	2.056
32	1.465	1.483	1.502	1.521	1.539	1.558	1.576	1.595	1.614	1.632	1.651	1.688	1.725	1.762	1.800	1.837	1.874	1.911	1.949	1.986	2.023
33	1.451	1.469	1.487	1.505	1.523	1.541	1.559	1.577	1.595	1.613	1.631	1.667	1.703	1.739	1.775	1.811	1.848	1.881	1.920	1.956	1.992
34	1.437	1.455	1.472	1.490	1.507	1.525	1.542	1.560	1.578	1.595	1.613	1.648	1.683	1.718	1.753	1.788	1.823	1.858	1.893	1.928	1.963
35	1.425	1.442	1.459	1.476	1.493	1.510	1.527	1.544	1.561	1.578	1.595	1.629	1.663	1.697	1.731	1.765	1.799	1.833	1.867	1.901	1.935
36	1.413	1.430	1.446	1.463	1.479	1.496	1.512	1.529	1.545	1.562	1.578	1.612	1.645	1.678	1.711	1.744	1.777	1.810	1.843	1.876	1.909
37	1.402	1.418	1.434	1.450	1.466	1.482	1.498	1.515	1.531	1.547	1.563	1.595	1.627	1.659	1.692	1.724	1.756	1.788	1.820	1.853	1.886
38	1.391	1.407	1.423	1.438	1.454	1.470	1.485	1.501	1.517	1.532	1.548	1.572	1.611	1.642	1.673	1.705	1.736	1.767	1.799	1.830	1.861
39	1.381	1.397	1.412	1.427	1.442	1.458	1.473	1.488	1.503	1.519	1.534	1.565	1.595	1.626	1.656	1.687	1.717	1.748	1.778	1.809	1.839
40	1.372	1.387	1.402	1.416	1.431	1.446	1.461	1.476	1.491	1.506	1.521	1.550	1.580	1.610	1.640	1.669	1.729	1.759	1.789	1.818	
42	1.354	1.368	1.382	1.397	1.411	1.425	1.439	1.453	1.468	1.482	1.496	1.524	1.553	1.581	1.609	1.638	1.666	1.694	1.723	1.751	1.779
44	1.338	1.352	1.365	1.379	1.392	1.406	1.419	1.433	1.446	1.460	1.473	1.500	1.527	1.554	1.582	1.609	1.636	1.663	1.690	1.717	1.744
46	1.323	1.336	1.349	1.362	1.375	1.388	1.401	1.411	1.427	1.440	1.453	1.479	1.505	1.530	1.556	1.582	1.608	1.634	1.660	1.686	1.712
48	1.310	1.322	1.335	1.347	1.359	1.372	1.384	1.397	1.409	1.421	1.434	1.459	1.483	1.508	1.533	1.558	1.583	1.608	1.632	1.657	1.682
50	1.297	1.309	1.321	1.333	1.345	1.357	1.369	1.381	1.393	1.405	1.417	1.440	1.464	1.488	1.512	1.536	1.559	1.583	1.607	1.631	1.655
52	1.286	1.297	1.309	1.320	1.332	1.343	1.355	1.366	1.378	1.389	1.400	1.423	1.444	1.469	1.492	1.515	1.538	1.561	1.584	1.607	1.629
54	1.275	1.286	1.297	1.308	1.320	1.331	1.342	1.353	1.364	1.375	1.386	1.408	1.430	1.452	1.474	1.496	1.518	1.540	1.562	1.584	1.606
56	1.266	1.276	1.287	1.297	1.308	1.319	1.329	1.340	1.351	1.361	1.372	1.393	1.414	1.436	1.457	1.478	1.499	1.521	1.542	1.563	1.585
58	1.256	1.267	1.277	1.287	1.297	1.308	1.318	1.328	1.339	1.349	1.359	1.380	1.400	1.421	1.441	1.462	1.482	1.503	1.523	1.544	1.564
60	1.248	1.258	1.268	1.278	1.288	1.297	1.307	1.317	1.327	1.337	1.347	1.367	1.387	1.407	1.426	1.446	1.466	1.486	1.506	1.526	1.546
65	1.229	1.238	1.247	1.256	1.265	1.275	1.284	1.293	1.302	1.311	1.320	1.339	1.357	1.375	1.394	1.412	1.430	1.449	1.467	1.485	1.504
70	1.212	1.221	1.229	1.238	1.246	1.255	1.263	1.272	1.281	1.289	1.298	1.315	1.332	1.349	1.368	1.383	1.400	1.417	1.434	1.451	1.468
75	1.198	1.206	1.214	1.222	1.230	1.238	1.246	1.254	1.262	1.270	1.278	1.294	1.309	1.325	1.341	1.357	1.373	1.389	1.405	1.421	1.436

 NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 3

$$\frac{b_p}{b_w} = 0.5 - \text{Continued}$$

$$\frac{t_w}{t_s} = 0.79$$

b_w/t_w	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
b_s/t_s																					
25	1.908	1.945	1.983	2.020	2.058	2.095	2.133	2.170	2.207	2.245	2.282	2.357	2.432	2.507	2.582	2.657	2.732	2.807	2.881	2.956	3.031
26	1.873	1.909	1.945	1.981	2.017	2.053	2.089	2.125	2.161	2.197	2.233	2.305	2.377	2.449	2.521	2.593	2.665	2.737	2.809	2.881	2.953
27	1.841	1.875	1.910	1.945	1.979	2.014	2.049	2.083	2.118	2.153	2.187	2.257	2.326	2.395	2.465	2.534	2.603	2.673	2.742	2.811	2.881
28	1.811	1.844	1.877	1.911	1.944	1.978	2.011	2.045	2.078	2.111	2.145	2.212	2.279	2.346	2.412	2.479	2.546	2.613	2.680	2.747	2.814
29	1.783	1.815	1.847	1.879	1.912	1.944	1.976	2.009	2.041	2.073	2.105	2.170	2.235	2.299	2.364	2.428	2.493	2.557	2.622	2.686	2.751
30	1.756	1.788	1.819	1.850	1.881	1.913	1.944	1.975	2.006	2.037	2.069	2.131	2.193	2.256	2.318	2.381	2.443	2.505	2.568	2.630	2.693
31	1.732	1.762	1.793	1.823	1.853	1.883	1.913	1.943	1.974	2.004	2.034	2.095	2.155	2.215	2.276	2.336	2.396	2.457	2.517	2.578	2.638
32	1.709	1.738	1.768	1.797	1.826	1.856	1.885	1.914	1.943	1.973	2.002	2.060	2.119	2.177	2.236	2.294	2.353	2.411	2.470	2.528	2.587
33	1.688	1.716	1.744	1.773	1.801	1.830	1.858	1.886	1.915	1.943	1.971	2.028	2.085	2.142	2.198	2.255	2.312	2.369	2.425	2.482	2.539
34	1.668	1.695	1.723	1.750	1.778	1.805	1.833	1.860	1.888	1.915	1.943	1.998	2.053	2.108	2.163	2.218	2.273	2.328	2.383	2.438	2.494
35	1.648	1.675	1.702	1.729	1.755	1.782	1.809	1.836	1.862	1.889	1.916	1.969	2.023	2.076	2.130	2.183	2.237	2.290	2.344	2.397	2.451
36	1.630	1.656	1.682	1.708	1.734	1.760	1.786	1.812	1.838	1.864	1.890	1.942	1.994	2.047	2.099	2.151	2.203	2.255	2.307	2.359	2.411
37	1.613	1.639	1.664	1.689	1.715	1.740	1.765	1.790	1.816	1.841	1.866	1.917	1.968	2.018	2.069	2.119	2.170	2.221	2.271	2.322	2.372
38	1.597	1.622	1.647	1.671	1.696	1.720	1.745	1.770	1.794	1.819	1.844	1.893	1.942	1.991	2.041	2.090	2.139	2.189	2.238	2.287	2.336
39	1.582	1.606	1.630	1.654	1.678	1.702	1.726	1.750	1.774	1.798	1.822	1.870	1.918	1.966	2.014	2.062	2.110	2.158	2.206	2.254	2.302
40	1.567	1.591	1.614	1.638	1.661	1.684	1.708	1.731	1.755	1.778	1.801	1.848	1.895	1.942	1.989	2.035	2.082	2.129	2.176	2.223	2.270
42	1.540	1.563	1.585	1.607	1.630	1.652	1.674	1.696	1.719	1.741	1.763	1.808	1.852	1.897	1.942	1.986	2.031	2.075	2.120	2.165	2.209
44	1.516	1.537	1.558	1.580	1.601	1.622	1.643	1.665	1.686	1.707	1.729	1.771	1.811	1.856	1.899	1.941	1.984	2.026	2.069	2.112	2.154
46	1.493	1.514	1.534	1.554	1.575	1.595	1.615	1.636	1.656	1.677	1.697	1.738	1.778	1.819	1.860	1.900	1.941	1.982	2.023	2.063	2.104
48	1.473	1.492	1.512	1.531	1.551	1.570	1.590	1.609	1.629	1.648	1.668	1.707	1.746	1.785	1.824	1.863	1.902	1.941	1.980	2.019	2.058
50	1.454	1.473	1.491	1.510	1.529	1.548	1.566	1.585	1.604	1.622	1.641	1.679	1.716	1.753	1.791	1.828	1.866	1.903	1.941	1.976	2.016
52	1.436	1.454	1.472	1.490	1.508	1.526	1.544	1.562	1.580	1.598	1.616	1.652	1.688	1.724	1.760	1.796	1.833	1.869	1.905	1.941	1.977
54	1.420	1.438	1.455	1.472	1.490	1.507	1.524	1.542	1.559	1.576	1.594	1.628	1.663	1.698	1.732	1.767	1.802	1.836	1.871	1.906	1.940
56	1.405	1.422	1.439	1.455	1.472	1.489	1.506	1.522	1.539	1.556	1.572	1.608	1.639	1.673	1.706	1.740	1.773	1.806	1.840	1.873	1.907
58	1.391	1.407	1.421	1.440	1.456	1.472	1.488	1.504	1.520	1.537	1.553	1.585	1.617	1.650	1.682	1.714	1.746	1.779	1.811	1.843	1.875
60	1.378	1.394	1.409	1.425	1.441	1.456	1.472	1.487	1.503	1.519	1.534	1.565	1.597	1.628	1.659	1.690	1.722	1.753	1.784	1.815	1.846
65	1.349	1.361	1.378	1.392	1.407	1.421	1.436	1.450	1.464	1.479	1.493	1.522	1.551	1.580	1.608	1.637	1.666	1.695	1.724	1.752	1.781
70	1.324	1.338	1.351	1.364	1.378	1.391	1.404	1.418	1.431	1.445	1.458	1.485	1.511	1.538	1.565	1.592	1.618	1.645	1.672	1.699	1.725
75	1.303	1.315	1.328	1.340	1.353	1.365	1.377	1.390	1.402	1.415	1.427	1.452	1.477	1.502	1.527	1.552	1.577	1.602	1.627	1.652	1.677

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 3

$$\frac{b_F}{b_W} = 0.5 - \text{Concluded}$$

$$\frac{t_W}{t_S} = 1.00$$

b_W/t_W	20	21	22	23	24	25	26	27	28	29	30	32	34	36	38	40	42	44	46	48	50
b_S/t_S																					
25	2.407	2.467	2.527	2.587	2.647	2.707	2.767	2.827	2.887	2.947	3.007	3.127	3.247	3.367	3.487	3.607	3.727	3.847	3.967	4.087	
26	2.353	2.410	2.468	2.526	2.583	2.641	2.699	2.756	2.814	2.872	2.930	3.045	3.160	3.276	3.391	3.506	3.622	3.737	3.853	3.968	
27	2.302	2.358	2.414	2.469	2.525	2.580	2.636	2.691	2.747	2.802	2.858	2.969	3.080	3.191	3.302	3.414	3.525	3.636	3.747	3.858	
28	2.256	2.310	2.363	2.417	2.470	2.524	2.577	2.631	2.685	2.738	2.792	2.899	3.006	3.113	3.220	3.327	3.435	3.542	3.649	3.756	
29	2.213	2.264	2.316	2.368	2.420	2.471	2.523	2.575	2.626	2.678	2.730	2.833	2.937	3.040	3.144	3.247	3.351	3.454	3.558	3.661	
30	2.172	2.222	2.272	2.322	2.372	2.422	2.472	2.522	2.572	2.622	2.672	2.772	2.872	2.972	3.072	3.172	3.272	3.372	3.472	3.572	
31	2.134	2.183	2.231	2.280	2.328	2.376	2.425	2.473	2.522	2.570	2.618	2.715	2.812	2.909	3.005	3.102	3.199	3.296	3.392	3.489	
32	2.099	2.146	2.193	2.240	2.286	2.333	2.380	2.427	2.474	2.521	2.568	2.661	2.755	2.849	2.943	3.036	3.130	3.224	3.318	3.411	
33	2.066	2.111	2.157	2.202	2.248	2.293	2.338	2.384	2.429	2.475	2.520	2.611	2.702	2.793	2.884	2.975	3.066	3.157	3.248	3.338	
34	2.034	2.078	2.123	2.168	2.211	2.254	2.299	2.343	2.387	2.431	2.476	2.564	2.652	2.740	2.828	2.917	3.009	3.093	3.181	3.270	
35	2.005	2.048	2.090	2.133	2.176	2.219	2.262	2.305	2.348	2.390	2.433	2.519	2.605	2.690	2.776	2.862	2.948	3.033	3.119	3.205	
36	1.977	2.019	2.060	2.102	2.144	2.185	2.227	2.269	2.310	2.352	2.394	2.477	2.560	2.644	2.727	2.810	2.894	2.977	3.060	3.144	
37	1.950	1.993	2.032	2.072	2.113	2.153	2.194	2.234	2.275	2.315	2.356	2.437	2.518	2.599	2.680	2.761	2.842	2.923	3.005	3.086	
38	1.925	1.965	2.004	2.044	2.083	2.123	2.162	2.202	2.241	2.281	2.320	2.399	2.478	2.557	2.636	2.715	2.794	2.873	2.952	3.031	
39	1.902	1.940	1.979	2.017	2.056	2.094	2.133	2.171	2.211	2.248	2.286	2.363	2.440	2.517	2.594	2.671	2.748	2.825	2.902	2.979	
40	1.879	1.917	1.954	1.992	2.029	2.067	2.104	2.142	2.179	2.217	2.254	2.329	2.404	2.479	2.554	2.629	2.704	2.779	2.854	2.929	
42	1.837	1.873	1.909	1.944	1.980	2.016	2.052	2.087	2.123	2.159	2.195	2.266	2.337	2.409	2.480	2.552	2.623	2.695	2.766	2.837	
44	1.799	1.833	1.867	1.901	1.936	1.970	2.004	2.038	2.072	2.106	2.140	2.208	2.277	2.345	2.413	2.481	2.549	2.617	2.686	2.754	
46	1.764	1.797	1.830	1.862	1.895	1.928	1.960	1.993	2.025	2.058	2.091	2.156	2.221	2.286	2.351	2.417	2.482	2.547	2.612	2.678	
48	1.733	1.764	1.795	1.826	1.858	1.889	1.920	1.951	1.983	2.014	2.045	2.108	2.170	2.233	2.295	2.358	2.420	2.483	2.545	2.608	
50	1.703	1.733	1.763	1.793	1.823	1.853	1.883	1.913	1.943	1.973	2.003	2.063	2.123	2.183	2.243	2.303	2.363	2.423	2.483	2.543	
52	1.676	1.705	1.734	1.763	1.792	1.821	1.849	1.878	1.907	1.936	1.965	2.022	2.080	2.138	2.196	2.253	2.311	2.369	2.426	2.484	
54	1.651	1.679	1.707	1.735	1.762	1.790	1.818	1.846	1.873	1.901	1.929	1.985	2.040	2.096	2.151	2.207	2.262	2.318	2.374	2.429	
56	1.628	1.655	1.682	1.708	1.735	1.762	1.789	1.815	1.842	1.869	1.896	1.949	2.003	2.057	2.110	2.164	2.217	2.271	2.324	2.378	
58	1.606	1.632	1.658	1.684	1.710	1.736	1.761	1.787	1.813	1.839	1.865	1.917	1.968	2.020	2.072	2.124	2.175	2.227	2.279	2.330	
60	1.586	1.611	1.636	1.661	1.686	1.711	1.736	1.761	1.786	1.811	1.836	1.886	1.936	1.986	2.036	2.086	2.136	2.186	2.236	2.286	
65	1.541	1.564	1.587	1.610	1.633	1.656	1.679	1.703	1.726	1.749	1.772	1.818	1.864	1.910	1.956	2.003	2.049	2.095	2.141	2.187	
70	1.502	1.524	1.545	1.567	1.588	1.610	1.631	1.652	1.674	1.695	1.717	1.760	1.802	1.845	1.888	1.931	1.974	2.017	2.060	2.102	
75	1.469	1.489	1.509	1.529	1.549	1.569	1.589	1.609	1.629	1.649	1.669	1.709	1.749	1.789	1.829	1.869	1.909	1.949	1.989	2.029	

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 4

VALUES AND COMPUTATIONS FOR OBTAINING IDEAL DESIGN

$$[P_i = 3.0 \text{ kips/in.}; c = 1]$$

L (in.)	$\frac{P_i}{L/\sqrt{c}}$ (kips/in.)	Step 1			Step 2		Step 3	Step 4	Step 5		
		$\frac{t_w}{t_s}$	$\frac{b_s}{t_s}$	$\frac{b_w}{t_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{A_i}{t_s}$	t_s (in.)	t_w (in.)	b_s (in.)	b_w (in.)	
10	0.30	0.51	27	26	a34.0	1.427	a0.0618	a0.0315	a1.67	a0.82	
		.63	28	25	35.6	1.602	.0526	.0331	1.47	.83	
		.79	29	24	36.7	1.860	.0440	.0348	1.28	.83	
		1.00	29	24	37.4	2.337	.0343	.0343	1.00	.82	
20	.15	.51	32	32	28.7	1.429	.0732	.0373	2.34	1.19	
		.63	33	31	a30.4	1.612	a0.0612	a0.0386	a2.02	a1.20	
		.79	34	29	31.6	1.862	.0510	.0403	1.73	1.17	
		1.00	35	28	32.2	2.268	.0411	.0411	1.44	1.15	
30	.10	.51	34	37	25.0	1.457	.0824	.0421	2.80	1.56	
		.63	35	35	a27.1	1.640	a0.0675	a0.0425	a2.36	a1.49	
		.79	37	33	27.8	1.886	.0572	.0452	2.12	1.49	
		1.00	38	31	28.6	2.278	.0461	.0461	1.75	1.43	

^aValues indicating designs that approach requirement of $t_s = 0.064$ in.

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 5

VALUES AND COMPUTATIONS FOR OBTAINING PRACTICAL DESIGN BY SHORT METHOD

$$[P_1 = 3.0 \text{ kips/in.}; L = 20 \text{ in.}; c = 1"; t_S = 0.064 \text{ in.}; \frac{t_W}{t_S} = 0.79]$$

Step 1	Step 2		Step 3	Step 4	Step 5			Step 6		Step 7				
$\frac{P_1}{L/\sqrt{c}}$ (kips/in.)	b_S in.	b_W in.	$\bar{\sigma}_f$ (ksi)	A_1 t_S	t_S (in.)	$\frac{b_S}{t_S}$	$\frac{b_W}{t_W}$	$\bar{\sigma}_f$ (ksi)	A_1 t_S	P_1 kips/in.	t_W (in.)	b_S (in.)	b_W (in.)	σ_{or} (ksi)
0.15	30 35 40 50	30 30 28 26	30.9 31.7 29.7 27.1	2.006 1.862 1.711 1.534	0.01484 .0508 .0590 .0722	43.3	26.1	28.8	1.619	2.98	0.051	2.77	1.33	23.5

TABLE 6

VALUES AND COMPUTATIONS FOR OBTAINING DESIGN FOR MAXIMUM STRUCTURAL EFFICIENCY

$$P_1 = 3.0 \text{ kips/in.}; \quad L = 20 \text{ in.}; \quad c = 1; \quad t_s = 0.064 \text{ in.}; \quad \frac{t_w}{t_s} = 0.79$$

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 7
TEST DATA ON WHICH DESIGN CHARTS ARE BASED FOR 24S-T ALUMINUM-ALLOY FLAT PANELS WITH LONGITUDINAL Z-SECTION STIFFENERS

$$\frac{t_w}{t_s} = 0.51$$

$\frac{b_s}{t_s}$	$\frac{b_w}{t_w}$	$\frac{b_f}{t_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.)	b_s	$\frac{b_w}{t_s}$	$\frac{b_f}{t_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.)	b_s	$\frac{b_w}{t_w}$	$\frac{b_f}{t_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.)	b_s	$\frac{b_w}{t_w}$	$\frac{b_f}{t_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.)
25	20	0.4	37.0	0.646	35	25	0.5	32.3	0.486	50	25	0.4	25.9	0.431	75	25	0.3	21.0	0.378
			33.7	.365		31.4		.271			24.0		.217			18.6		.191	
			26.2	.188		27.0		.163			22.2		.144			16.5		.118	
			14.8	.082		14.4		.062			13.6		.061			13.7		.069	
			26.3	.550	30	31.4	.3	.427			26.5	.5	.403			21.0	.4	.360	
			33.8	.298		30.7		.235			24.9		.217			19.4		.189	
			26.0	.159		27.0		.145			22.8		.140			17.5		.121	
			15.6	.066		16.8		.064			15.9		.069			12.2		.059	
			33.8	.442		30.7	.4	.391			25.6	.3	.355			20.9	.5	.343	
			31.3	.227		31.0		.227			24.3		.192			19.4		.182	
			26.0	.131		27.4		.141			22.6		.123			17.6		.115	
			15.4	.056		17.4		.064			19.7		.061			12.8		.061	
			29.3	.295	40	31.1	.5	.392			25.0	.4	.323			19.9	.3	.289	
			23.9	.137		30.3		.242			23.8		.176			18.8		.155	
			22.5	.090		27.5		.158			22.6		.117			16.4		.094	
			16.8	.048		17.5		.062			16.4		.060			13.6		.055	
			25.9	.222		26.5	.4	.252			25.5	.5	.321			19.1	.4	.268	
			20.5	.101		25.6		.162			24.4		.174			19.8		.156	
			17.7	.061		23.6		.091			23.0		.116			17.7		.098	
			16.4	.049		16.8		.046			16.5		.059			15.4		.055	
35	20	.3	31.5	.644	50	23.9	.4	.183		40	23.3	.4	.219		.5	20.6	.4	.272	
			30.6	.358		21.8		.097			22.2		.118			19.8		.148	
			25.6	.211		20.8		.066			20.2		.078			17.0		.089	
			14.9	.088		16.0		.042			15.7		.041			13.2		.049	
			31.2	.611	50	26.2	.5	.577			21.3	.4	.159			19.2	.4	.186	
			31.2	.347		24.0		.300			19.1		.080			17.9		.100	
			25.8	.203		21.9		.193			18.0		.054			16.8		.065	
			15.2	.086		15.0		.092			15.6		.037			12.8		.035	
			31.4	.587	75	26.7	.4	.557			22.4	.3	.591			17.0	.4	.129	
			30.3	.325		25.1		.297			18.4		.252			16.2		.070	
			26.4	.202		21.2		.177			16.5		.158			14.9		.046	
			13.4	.073		14.6		.087			12.2		.084			11.7		.025	
			32.5	.533		23.7	.5	.531			20.5	.4	.471						
			31.7	.295		22.6		.266			19.2		.245						
			26.6	.171		21.1		.170			16.7		.149						
			16.8	.078		15.0		.086			12.0		.078						
			30.9	.477	25	25.2	.3	.430			21.2	.5	.454						
			31.2	.278		24.7		.211			18.6		.227						
			26.9	.169		20.8		.140			17.2		.148						
			13.4	.060		15.2		.070			13.5		.065						

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 7
TEST DATA - Continued

$$\frac{t_w}{t_s} = 0.63$$

$\frac{b_g}{t_g}$	$\frac{b_w}{t_w}$	$\frac{b_F}{b_w}$	$\bar{\sigma}_F$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.) in.)	b_g	$\frac{b_w}{t_w}$	$\frac{b_F}{b_w}$	$\bar{\sigma}_F$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.) in.)	b_g	$\frac{b_w}{t_w}$	$\frac{b_F}{b_w}$	$\bar{\sigma}_F$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.) in.)	b_g	$\frac{b_w}{t_w}$	$\frac{b_F}{b_w}$	$\bar{\sigma}_F$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.) in.)
25	20	0.4	38.9 33.4 24.9 14.3	0.626 .307 .159 .065	35	25	0.5	32.5 30.9 28.2 17.4	0.429 .238 .158 .068	50	25	0.4	28.0 25.0 20.4 13.5	0.323 .168 .094 .044	75	25	0.3	22.7 19.2 15.6 12.1	0.281 .134 .076 .043
		.4	38.9 32.4 24.6 14.2	.517 .212 .132 .054	30	.3	30.7 29.9 27.9 17.9	.335 .186 .122 .055	.5		28.0 26.2 23.0 17.2	.365 .183 .117 .065	.4	22.1 19.8 16.4 11.3		.257 .132 .076 .038			
		.4	36.3 30.9 24.6 16.6	.420 .199 .113 .055	.4	30.7 31.4 28.1 18.5	.329 .193 .121 .057	.3	26.0 24.9 22.9 16.3		.279 .152 .097 .049	.5	22.7 20.9 18.1 13.8	.304 .161 .097 .053					
		.4	29.4 24.2 23.5 15.6	.275 .131 .068 .042	.5	30.4 29.1 27.5 18.0	.314 .173 .115 .054	.4	25.8 26.9 23.2 16.2		.266 .167 .095 .048	.3	20.6 19.6 18.6 13.8	.226 .121 .081 .043					
	50	.4	25.2 22.1 18.7	.210 .104 .061	40	.4	27.8 24.9 23.8 16.9	.235 .118 .080 .042	.5		26.2 24.0 22.3 17.1	.261 .135 .088 .049	.4	21.2 21.0 18.8 14.1		.219 .128 .079 .042			
		-----	-----	-----															
35	20	.3	32.0 32.8 25.4 15.6	.516 .304 .168 .072	50	.4	24.0 21.9 19.2	.173 .089 .054	40		.4	23.8 22.4 21.4 17.4	.187 .101 .067 .040	.5	21.0 20.2 18.0 14.2	.207 .121 .075 .040			
		.4	33.5 34.0 28.3 15.4	.524 .306 .179 .069	50	20	.3	28.2 25.0 21.8 15.1	.459 .233 .164 .071	50	.4	21.5 19.6 17.9 16.9	.141 .071 .046 .037	40	.4	18.6 18.2 17.5 13.4	.138 .081 .053 .029		
		.5	33.5 32.0 29.4 17.7	.506 .275 .178 .075	.4	28.3 25.8 22.2 14.5	.447 .230 .140 .065	75	20	.3	22.0 20.2 15.8 13.0	.381 .206 .110 .065	50	.4	17.7 17.5 16.0 13.1	.105 .061 .039 .024			
		25	33.1 32.4 24.7 14.4	.430 .243 .127 .055	.5	27.4 25.5 22.9 16.3	.410 .216 .137 .069	.4	22.7 21.3 17.2 12.5	.374 .200 .113 .059									
	25	.4	33.8 32.4 26.1 15.1	.419 .235 .130 .055	25	.3	27.4 25.0 20.6 13.5	.329 .171 .099 .047	.5	22.4 20.5 18.5 13.9	.372 .181 .114 .064								

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 7
TEST DATA - Continued

$$\frac{t_w}{t_s} = 0.79$$

$\frac{b_g}{t_s}$	$\frac{b_w}{t_w}$	$\frac{b_p}{b_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.) in.	$\frac{b_g}{t_s}$	$\frac{b_w}{t_w}$	$\frac{b_p}{b_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.) in.	$\frac{b_g}{t_s}$	$\frac{b_w}{t_w}$	$\frac{b_p}{b_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.) in.	
35	20	0.3	34.5 34.4 26.9 16.5	0.470 .270 .118 .063	50	20	0.3	28.7 27.2 23.4 16.2	0.369 .205 .123 .061	75	20	0.3	22.9 21.7 17.4 12.7	0.306 .167 .092 .049	
		.4	35.7 34.6 29.7 16.8	.472 .265 .157 .062				29.6 27.2 23.2 16.4	.374 .194 .115 .059				.4	24.7 23.1 20.4 14.2	.313 .168 .106 .052
		.5	34.8 33.7 27.7 17.6	.449 .249 .111 .065				29.7 28.5 23.1 16.4	.365 .201 .112 .082				.5	24.2 22.3 19.4 13.3	.298 .157 .094 .046
		.3	37.0 32.6 28.2 17.6	.394 .202 .126 .056				28.9 28.2 24.4 16.9	.295 .165 .100 .049				-----	-----	-----
		.4	35.2 33.3 29.3 17.1	.374 .204 .123 .052				29.2 27.8 23.3 17.0	.277 .158 .092 .048				.4	24.4 22.6 19.5 13.4	.236 .125 .075 .037
		.5	33.2 33.8 17.7	.357 .213 .056				28.5 27.4 23.5 17.2	.309 .169 .102 .053				.5	23.6 22.9 19.9 14.2	.242 .137 .083 .041
	30	0.3	33.8 32.0 28.5 18.6	.340 .181 .110 .052	30	.3	27.8 26.6 23.6 17.6	.250 .137 .084 .044	30	.3	22.9 22.3 19.2 14.4	-----	-----	-----	
		.4	32.5 31.7 28.2 17.5	.313 .173 .107 .048				27.6 26.8 22.6 17.2	.238 .134 .079 .043			.4	23.6 21.6 19.7 14.0	.198 .102 .067 .033	
		.5	31.2 30.2 28.5 17.1	.302 .162 .101 .046				26.9 25.0 23.7 16.5	.234 .122 .084 .040			.5	22.5 20.9 18.9 14.8	.182 .095 .061 .037	

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS

TABLE 7
TEST DATA - Concluded

$$\frac{t_w}{t_s} = 1.00$$

$\frac{b_s}{t_s}$	$\frac{b_w}{t_w}$	$\frac{b_F}{b_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.)	$\frac{b_s}{t_s}$	$\frac{b_w}{t_w}$	$\frac{b_F}{b_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.)	$\frac{b_s}{t_s}$	$\frac{b_w}{t_w}$	$\frac{b_F}{b_w}$	$\bar{\sigma}_f$ (ksi)	$\frac{P_1}{L/\sqrt{c}}$ (kips/in.)
35	20	0.3	36.3 32.8 26.8 17.6	0.430 .215 .123 .059	50	20	0.3	30.2 27.8 23.2 18.5	0.320 .165 .096 .051	75	20	0.3	24.0 23.2 18.3 14.6	0.235 .129 .072 .041
		.4	36.7 33.7 27.3 17.5	.418 .222 .122 .057				31.6 29.1 24.1 16.7	.322 .167 .096 .048				.4 25.9 23.8 20.1 14.3	.245 .128 .076 .039
		.5	36.1 34.1 28.0 17.2	.414 .223 .130 .057				32.0 28.2 23.2 16.5	.326 .164 .092 .049				.5 26.1 24.7 20.2 14.8	.250 .129 .077 .041
	25	.3	33.5 31.7 27.3 18.1	.333 .180 .108 .052	25	.3	29.6 27.1 24.3 17.2	.260 .134 .084 .042	25	.3	24.2 22.4 20.7 14.7	24.2 22.4 20.7 14.7	.200 .101 .066 .033	
		.4	35.4 31.8 28.7 16.4	.347 .177 .112 .047			31.0 27.7 24.5 16.0	.262 .138 .083 .046	.4 25.8 24.1 21.1 14.3		.199 .106 .065 .033			
		.5	35.3 33.1 25.3 16.8	.358 .190 .103 .048			30.8 27.9 23.9 17.5	.270 .139 .084 .044	.5 25.5 23.9 21.5 14.1		.199 .108 .067 .032			
	30	.3	33.1 29.4 23.6 15.0	.290 .149 .084 .037	30	.3	28.2 25.9 23.3 16.6	.213 .112 .070 .037	30	.3	23.9 21.6 19.6 14.5	23.9 21.6 19.6 14.5	.161 .084 .053 .028	
		.4	33.3 31.6 23.8 15.1	.291 .163 .083 .038			29.0 27.5 21.8 16.6	.218 .120 .065 .036	.4 24.2 22.8 20.8 14.8		.160 .086 .056 .028			
		.5	32.7 30.1 26.0 13.5	.300 .160 .095 .036			28.1 26.3 22.7 16.1	.216 .117 .070 .036	.5 24.0 22.4 20.2 14.1		.162 .086 .055 .027			

NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICS




Figure 1. - Symbols for panel dimensions.




Fig. 2

NACA ARR No. L5F15

Figure 2-Concluded.




Fig. 3

NACA ARR No. L5F15




Figure 3.-Design chart for 24S-T aluminum-alloy flat panels with Z-section stiffeners;
 $t_w/t_s = 0.63$; ($b_A/t_w = 10.9$;
 $r_A/t_w = 3$; $r_B/t_w = 4$; and
 $b_F/b_W = 0.3$ to 0.5)




Figure 3.-Concluded.




Figure 4.-Design chart for 24S-T aluminum-alloy flat panels with Z-section stiffeners; $t_w/t_s = 0.79$; ($b_A/t_w = 9.8$; $r_A/t_w = 3$; $r_F/t_w = 4$; and $b_F/b_w = 0.3$ to 0.5)




Figure 4.-Concluded.




Figure 5.- Design chart for 24S-T aluminum-alloy flat panels with Z-section stiffeners;
 $t_w/t_s = 1.00$; $(b_A/t_w = 8.6$;
 $r_A/t_w = 3$; $r_F/t_w = 4$; and
 $b_F/b_w = 0.3$ to 0.5)




Figure 5.-Concluded.





Figure 6.- Highest values of average stress at failure for 24S-T aluminum-alloy flat panels with Z-section stiffeners, with values of b_s/t_s and b_w/t_w needed to realize these stresses.




Figure 7.- Designs of 24S-T aluminum-alloy panels 10 inches long with $P_i = 3.0$ kips/inch, $c=1$, and $t_s = 0.064$ inch.

Fig. 8.

NACA ARR No. L5F15




Figure 8.- Designs of 24S-T aluminum-alloy panels 20 inches long with $P_i = 3.0$ kips/inch, $c=1$, and $t_s = 0.064$ inch.


NATIONAL ADVISORY
COMMITTEE FOR AERONAUTICSFigure 9.- Designs of 24S-T aluminum-alloy panels 30 inches long with $P_i=3.0$ kips/inch, $c=1$, and $t_s=0.064$ inch.

Fig. 10

NACA ARR No. L5F15




Figure 10.-Plot for obtaining practical design by short method. $P_i = 3.0$ kips/inch; $L = 20$ inches;
 $c = 1$; $t_s = 0.064$ inch; $t_w/t_s = 0.79$.




Figure 11.-Plot for obtaining design for maximum structural efficiency. $P_i = 3.0$ kips/inch; $L = 20$ inches; $c = l$; $t_s = 0.064$ inch; $t_w/t_s = 0.79$.

Fig. 12

NACA ARR No. 15F15




Figure 12.-Average stress at local failure for 24S-T aluminum-alloy flat compression panels with longitudinal Z-section stiffeners. $b_F/b_W=0.4$.




Figure 13.-Typical design curve for panels that do not buckle.




Figure 14.-Typical design curve for panels that buckle.

Fig. 15

NACA ARR No. L5F15




Figure 15.- Stress for local buckling of 24S-T aluminum-alloy flat panels with Z-section stiffeners. $b_F/b_W=0.4$.





Figure 16.- Illustration of procedure used in preparation of design charts.

Fig. 17

NACA ARR No. L5F15

Figure 17.- Comparison of test data with design curves for 24S-T aluminum-alloy flat panels with Z-section stiffeners. $t_w/t_s = 0.51$.




Figure 18.-Comparison of test data with design curves for 24S-T aluminum-alloy flat panels with Z-section stiffeners. $t_w/t_s = 0.63$.

Fig. 19

NACA ARR No. L5F15




Figure 19.-Comparison of test data with design curves for 24S-T aluminum-alloy flat panels with Z-section stiffeners. $t_w/t_s = 0.79$.




Figure 20.-Comparison of test data with design curves for 24S-T aluminum-alloy flat panels with Z-section stiffeners. $t_w/t_s = 1.00$.

LANGLEY RESEARCH CENTER



3 1176 01363 8995